



SCPH-30000
SCPH-30001
SCPH-30002
SCPH-30003
SCPH-30004

SCPH-30000 series

SERVICE MANUAL

6th Edition

PlayStation®2



Sony Computer Entertainment Inc.
Customer Service Department
Published in Japan c 5. 2000 9-927-084-06

NOTICE

Copyright by Sony Computer Entertainment Inc. All rights reserved. No reproduced and transferred required except permission by Sony Computer Entertainment Inc. No commercial use and rental required.

REVISIONS.

This manual compiled by first edition of SCPH-30000, 30001, 30002, 30003, 30004 B, B', C, C', D type design data. Design and Specification will be subject to changed without notice. The latest versions of service manual, Technical memo, Technical information should be used together.

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY MARK $\triangle$ OR DOTTED LINE WITH MARK $\triangle$ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE PERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ !

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE $\triangle$ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS UBLIÉS PAR SONY.

CAUTION

Replace the battery with a Sony CR2032 battery. Use of any other type of battery may present the risk of fire or explosion. The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

CAUTION

The use of optical instruments with this product will increase eye Hazard. As the laser beam used in this CD/DVD player is harmful To eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

WARNING !!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION for electric shock

When power is ON, Don't touch to Power supply block, AC-inlet, Power switch and so on, not to get an electric shock at repair.

CAUTION for burning

When current is supplied, Some of part surface temperature like EE, GS, Regulator-IC, power supply, Optical device and so on. These part surface is become high temperature condition. When it repair, Don't touch them at a time during it surface is high temperature condition to take prevent against burning. Do repair after it is cooled down enough.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

ADVARSEL!

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

ADVARSEL

Eksplodingsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

VARNING

Explosionsfara vid felaktigt batteribyte. Använt samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan valmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

SAFETY CHECK-OUT


After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or cold-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the inter board wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out of the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the b+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metalized" knobs, screws, and all other exposed metal parts for ac leakage. Check leakage as described below.

LEAKAGE

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a Return to chassis, must not exceed 0.5 mA (500 micro-amperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the SIMPSON 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milli-ammeter. The Data Precision 245 digital multi-meter is suitable for this job
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated ac voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The SIMPSON 250 and SANWA SH-63TRD are examples of a passive VOM that is suitable. Nearly all battery operated digital multi-meters that have a 2V AC range are suitable.



NOTIFICATION for environmental assessment

This model is CR2032 lithium battery onboard inside on the GD MOUNT as Timer backup power. CR2032 life may be about 5 to 8 years so you have very few need for changing to new one. But if you have necessary to replaced to new one or disassemble for scrapping, you have to keep your country low, regulation, standard, etc. of environmental assessment and safty.

TABLE OF CONTENTS

SCPH-30001 (B, B')4-38

SCPH-30001 (C) 39-70

SCPH-30002/30003/30004 (C, C') 71-115

SCPH-30001D 116-138

SCPH-30002/30003/30004 (D, D')

1. Table of Contents and Specifications 139

2. Exploded Views

Overall and Main Block 140

MD Block..... 141

GH-010/GH-012 Block 142

GB-003/GB-004 and Plate Assy Block 142

Shield (A) Assy Block 142

Shield (B) Block..... 142

Fan and Rear Panel Block 142

Switch Block 142

3. Block Diagram for D type 143

4. Printed Wiring Boards and Schematic Diagrams
for SCPH-30002D/30003D/30004D

This Note is Common for Printed Wiring boards and
Schematic diagrams 144

GH-010..... 145

GB-003..... 154

SW-358 155

5. Electrical Parts List
for SCPH-30002D/30003D/30004D 156

6. Printed Wiring Boards and Schematic Diagrams
for SCPH-30003D'/30004D'

This Note is Common for Printed Wiring boards and
Schematic diagrams 162

GH-012..... 163

GB-004..... 172

SW-363 173

7. Electrical Parts List
for SCPH-30003D'/30004D' 174

SECTION 1
SPECIFICATIONS

General

Power requirements
220-240 V AC, 50/60 Hz

Power consumption
50 W

Dimensions
301 × 78 × 182 mm (w/h/d)

Mass
2.4 kg

Inputs/ Outputs on the front

Controller ports (2)

Memory card slots (2)

USB ports (2)

S400 (i-Link) port (1)

Inputs/Outputs on the rear

HDD bay slot (1)

Outputs on the rear

AV Multi out port (1)
RGB, Ycbcr, Y/C, Composite-video,
Audio-L/R, XGA

Digital out port (1)
Optical audio

Supplied accessories

AC power cord (1)


Euro-AV connector (1)
(for SCPH-30003, 30004)

A/V connecting cable (1)

Dualshock2 Analog controller (1)

SECTION 2
EXPLODED VIEWS

Overall and Main Block



CAUTION

The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.


CAUTION :
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

OVERALL AND MAIN BLOCK

Ref-No.	Part No.	Description	Remark	Place code
$\triangle$ 60	1-468-605-21	POWER BLOCK		#00
$\triangle$ 62	1-694-676-21	TERMINAL BOARD (FRONT)		#17
$\triangle$ 71	3-069-119-01	LABEL, MODEL NUMBER (AU)	for SCPH-30002D	#87
$\triangle$ 71	3-069-120-01	LABEL, MODEL NUMBER (CEK)	for SCPH-30003D/30003D'	#87
$\triangle$ 71	3-069-121-01	LABEL, MODEL NUMBER (CEL)	for SCPH-30004D/30004D'	#87
75	3-059-626-03	COVER, SCREW		#22
76	3-059-627-01	CAP		#22
84	3-067-170-01	TAPE (20X20), HARNESS STOPPER		#87
91	A-6705-342-A	MD BLOCK ASSY		#10
92	A-6705-401-A	SWITCH BLOCK ASSY		#87
93	X-3951-722-1	COVER ASSY, LOWER		#87
94	X-3951-721-1	COVER ASSY, UPPER		#87
106	X-3951-317-1	LID ASSY		#87
$\triangle$ 112	3-066-498-01	TAPE, VOID		#87
$\triangle$ 135	3-988-711-02	LABEL, LASER COUTION		#87
151	1-757-934-11	CABLE, FLAT (FFC-011)		#12
152	1-757-935-11	CABLE, FLAT (FFC-012)		#12
153	1-961-160-21	HARNESS (HS-059)		#12
156	3-068-669-02	SHIELD B		#16
157	3-068-674-01	SHEET, INSULATING		#16
158	3-068-675-02	SHIELD HDD		#87
161	3-070-120-01	SHEET, INTERCEPTION		#87
162	3-069-212-01	TAPE, HARNESS STOPPER		#16
B265	3-069-170-01	TAPPING (B2X6.5)		#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12		#87
BV316	3-325-679-91	SCREW (2 LOCK), +BV TAPPING		#87
GH010	A-6712-954-A	GH-010 MOUNT (32M M) Block	for SCPH-30003D/30004D	#25GB
GH010	A-6712-957-A	GH-010 MOUNT (64M M) Block	for SCPH-30002D	#25GB
GH010	A-6712-955-A	GH-010 MOUNT (64M M) Block	for SCPH-30003D/30004D	#25GB
GH010	A-6712-958-A	GH-010 MOUNT (64M R) Block	for SCPH-30002D	#25GB
GH010	A-6712-956-A	GH-010 MOUNT (64M R) Block	for SCPH-30003D/30004D	#25GB
GH012	A-6712-985-A	GH-012 MOUNT (32M R) Block	for SCPH-30003D' /30004D'	#25GH
GH012	A-6712-986-A	GH-012 MOUNT (64M R) Block	for SCPH-30003D' /30004D'	#25GH
M225	3-069-169-01	SCREW (M2X2.5)		#87
M354	3-059-622-02	SCREW (M3X54), HEAD TAPPING		#87
M360	3-069-168-01	TITE (CZN), M3X6 +BV S		#87

for details
Click here.

MD Block




MD BLOCK

Ref-No.	Part No.	Description	Remark	Place code
2	8-835-733-01	MOTOR, DC SSC28C/C-NP		#10SP
2	1-763-700-12	MOTOR, DC (SPINDLE)		#10SP
3	1-763-639-21	MOTOR, DC		#10
5	3-059-845-01	SCREW (B2X6.5), SHAFT RETAINER		#10
7	X-3951-637-1	FRAME ASSY, SUB		#10
8	3-065-277-01	INSULATOR		#10
9	3-065-276-01	SCREW, STEP		#10
10	X-3951-606-1	CHASSIS ASSY, MAIN		#10
13	3-059-854-02	SHAFT, MAIN		#10
14	3-059-855-02	RACK		#10
16	3-060-399-01	SCREW, SKEW		#10
17	3-060-400-01	TAPPING (B2X6.5)		#10
22	3-062-728-01	Ø PLATE 3, MAIN M3X3.2		#10
23	8-820-141-10	DEVICE, OPICAL KHS-400B		#10OP
26	X-3951-607-2	CHASSIS ASSY, SUB		#10
27	X-3951-609-2	BRACKET ASSY, PULLEY		#10
28	X-3951-608-2	TRAY ASSY		#10TR
30	X-3951-610-2	FRAME ASSY, MAIN		#10
31	1-680-370-12	PWB, FLEXIBLE		#10
32	3-068-075-02	SCREW (SUB), STEP		#10
33	3-065-278-02	CAM, TILT		#10
34	3-068-076-01	SPRING (TILT), LEAF		#10
35	3-065-282-01	GUIDE (L)		#10
36	3-065-283-01	GUIDE (R)		#10
37	3-065-557-01	SCREW (M2X6.0)		#10
41	3-065-279-02	SCREW, CAM RETAINER		#10


for details
Click here

GH-010/GH-012 Block




Ref-No.	Part No.	Description	Place code
87	3-068-806-01	SHEET (DRIVER), ELECTRIC HEAT	#25GH
151	1-757-934-11	CABLE, FLAT (FFC-011)	#12
153	1-961-160-21	HARNESS (HS-059)	#12
GH010	A-6712-954-A	GH-010 MOUNT (32M M) for SCPH-30003D/30004D	#25GH
GH010	A-6712-957-A	GH-010 MOUNT (64M M) for SCPH-30002D	#25GH
GH010	A-6712-955-A	GH-010 MOUNT (64M M) for SCPH-30003D/30004D	#25GH
GH010	A-6712-958-A	GH-010 MOUNT (64M R) for SCPH-30002D	#25GH
GH010	A-6712-956-A	GH-010 MOUNT (64M R) for SCPH-30003D/30004D	#25GH
GH012	A-6712-985-A	GH-012 MOUNT (32M R) for SCPH-30003D'/30004D'	#25GH
GH012	A-6712-986-A	GH-012 MOUNT (64M R) for SCPH-30003D'/30004D'	#25GH

Fan and Rear Panel Block




Ref-No.	Part No.	Description	Place code
63	1-763-480-22	DC. FAN	#74
64	1-771-995-31	SWITCH, POWER (WITH AC INLET)	#00
159	3-068-676-11	PANEL, REAR	#87
BV312	3-325-679-21	SCREW, TAPPING +BV 3X12	#87

Shield (A) Assy Block




Ref-No.	Part No.	Description	Place code
97	X-3951-707-2	SHIELD (A) ASSY	#87
120	3-059-652-01	SHEET (A), ELECTRIC HEAT for SCPH-30002D/30003D/30004D	#16
143	3-066-277-01	SHEET (P), ELECTRIC HEAT for SCPH-30003D'/30004D'	#16
144	3-066-278-01	SHEET (Q), ELECTRIC HEAT for SCPH-30003D'/30004D'	#16

Shield (B) Block




Ref-No.	Part No.	Description	Place code
156	3-068-669-02	SHIELD B	#16
157	3-068-674-01	SHEET, INSULATING	#16

GB-003/GB-004 and Plate Assy Block



Ref-No.	Part No.	Description	Place code
61	1-528-174-41	BATTERY, LITHIUM (CR2032 TYPE)	#25GB
91	A-6705-342-A	MD BLOCK ASSY	#10
95	X-3951-099-1	PLATE ASSY, ORNAMENTAL	#87
153	1-961-160-21	HARNESS (HS-059)	#12
GB003	A-6712-923-A	GB-003 MOUNT for SCPH-30002D/30003D/30004D	#25GB
GB004	A-6712-984-A	GB-004 MOUNT for SCPH-30003D'/30004D'	#25GB


Switch Block



Ref-No.	Part No.	Description	Place code
50	3-059-665-03	BUTTON, SWITCH	#25SW
51	3-059-666-05	BRACKET, SWITCH	#25SW
52	7-685-105-11	TPG +P 2X8, TYPE 2, NON-SLIT	#25SW
53	A-6712-922-A	SW-358 MOUNT for SCPH-30002D/30003D/30004D	#25SW
53	A-6712-983-A	SW-363 MOUNT for SCPH-30003D'/30004D'	#25SW

SECTION 3

BLOCK DIAGRAM for D type



SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS
for SCPH-30002D/30003D/30004D

THIS NOTE IS COMMON FOR PRINTED WIRING
BOARDS AND SCHEMATIC DIAGRAMS.

Note on Printed Wiring Boards :

- Through hole is omitted.
-  : Pattern on the side which is seen.

Note on Schematic Diagram :

- Use caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor,
because it is damaged by the heat.
- All capacitors are in μF unless otherwise noted. pF : $\mu\mu\text{F}$ 50 WV
or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4 W (Chip resistors : 1/10W) unless
otherwise specified.
- Chip resistors are 1/8 W or 1/10 W unless otherwise noted.
 $\text{k}\Omega$: 1000Ω , $\text{M}\Omega$: $1000\text{ k}\Omega$.

Note :


The components
identified by mark  or
dotted line with mark  are
critical for safety.
Replace only with part
number specified.


Note :


Les composants identifiés par
une marque  sont critiques
pour la securite.
Ne les remplacer que par une
piece portant le nubero specifie.

Note on DC Power line :

Unit of voltage is V (volt)

- | | |
|---|--|
| • +12V :  | • +3.3V :  |
| • +8.0V :  | • +2.5V :  |
| • +5.0V :  | • +1.8V :  |
| • +3.5V :  | • +1.7V :  |
| • +3.4V :  | • +1.5V :  |
| • IN :  | • Main Signal Line :  |
| • OUT :  | |







BD3992F-E2 : for GH010-64MR
MM1537DFBE : for GH010-32MM & GH010-64MM

IC403

IC405
RS5C348A-E2

IC406
BR9080F-E2

IC401
S-80769SN-J0-T1

IC415
NJM2125F(Te2)

IC402
TMP87C807U-1V33

IC409
SN104809DBTR

IC413
LP2985IM5X-3.5

IC414
TA7808F(Te16L)

IC404
SN104809DBTR

IC407
PQ018PZ01ZP

IC408
PQ070XZ01ZP

IC410
SI-3026LSA-TL

IC411
MM3031JULE

IC412
ST-3025LSA-TL

- TRAY_LED_ON IC604 99 pin
- POFF_REQ IC604 96 pin, IC604 74 pin
- REGSTBY IC104 344 pin
- POFF_RDY IC504 95 pin, IC604 32 pin
- IPWRUP_EE IC104 345 pin
- ISYS_SRST IC303 80 pin
- PWRUP_IOP2 IC504 99 pin, IC604 6 pin
- TRAY_REQ IC303 81 pin
- MCNACK IC604 4 pin
- SLEEP IC504 94 pin, IC604 5 pin
- HDD_SET IC504 92 pin
- HDD_ACK IC104 342 pin
- REGST IC504 97 pin
- TS_CS IC105 7 pin
- TS_SI IC105 5 pin
- TS_RST IC303 54 pin, IC501 15 pin, IC504 105 pin, IC604 99 pin, IC605 63.83 pin, IC602 21 pin, IC603 7 pin, IC602 1 pin
- TS_SCK IC505 73 pin
- TRESETIN
- GND

GH-010 (4/7)

Reproduction Prohibited

IC518 : GH010-64MM & GH010-64MR

IC518

IC503

for GH010-32MM & GH010-32MR

IC506

for GH010-32MM & GH010-32MR

SCPH-30002D/30003D/30004D

C526, C543, R527 :
for GH010-64MM & GH010-64MR

TC7WB125FK (TE85R)

IC503

BOOT ROM

IC506

DVD ROM

IC502

SDMN18165CTM6S
DRAM

IC504

CXD2942AR
SPU2

IC505

BOOT + DVD ROM
for GH010-64MM & GH010-64MR

C505, C512, R510, R511 :
for GH010-32MM & GH010-32MR

IC501

CXD9611AR
HDD CONTROLLER


IC517

CS4335-KS
AUDIO DUC

GH-010 (5/7)

Reproduction Prohibited


TO HARD DISK DRIVE







— 152 —

Reproduction Prohibited







GB-003
A side




GB-003
A side




GB-003
B side



SW-358
A side



SW-358
B side



SW-358

SECTION 5
ELECTRICAL PARTS LIST
for SCPH-30002D/30003D/30004D GH010 MOUNT

NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
METAL : Metal-film resistor.
F : nonflammable
Unit is Ω.

- SEMICONDUCTORS
In each case, u : μ, for example :
uA . . . : μA . . . uPA . . . : μPA . . .
uPB . . . : μPB . . . uPC . . . : μPC . . . uPD . . . : μPD . . .
- CAPACITORS
uF : μF
- COILS
uH : μH

The components identified by mark △ or dotted line with mark. △ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref.	Part No.	Description
Dissimilarity Parts		
for SCPH-30002 GH010-64MM		

C408	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C526	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C543	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
IC403	8-759-688-08	IC MM1537DFBE
IC505	6-800-199-01	IC TC5364200FT-PA07
IC518	8-759-680-49	IC TC7WB125FK(TE85R)
IC604	8-752-922-01	IC CXP101064-303R-T6
R527	1-216-821-91	RES, CHIP 1.0K (1608)
for SCPH-30002 GH010-64MR		

C408	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C526	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C543	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
IC403	6-700-234-01	IC BD3992F-E2
IC505	6-800-199-01	IC TC5364200FT-PA07
IC518	8-759-680-49	IC TC7WB125FK(TE85R)
IC604	8-752-922-02	IC CXP101064-303R-T7
R527	1-216-821-91	RES, CHIP 1.0K (1608)
for SCPH-30003/-30004 GH010-32MM		

C408	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C505	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C512	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
IC403	8-759-688-08	IC MM1537DFBE
IC503	6-800-197-01	IC MR27V3202F-A7TPZ
IC506	6-800-198-01	IC MR27V1602E-74TPZ
IC604	8-752-921-99	IC CXP101064-202R-T6
R510	1-216-864-91	CONDUCTOR, CHIP (1608)
R511	1-216-864-91	CONDUCTOR, CHIP (1608)
for SCPH-30003/-30004 GH010-64MM		

C408	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C526	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C543	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
IC403	8-759-688-08	IC MM1537DFBE
IC505	6-800-196-01	IC TC5364200FT-PA06
IC518	8-759-680-49	IC TC7WB125FK(TE85R)
IC604	8-752-921-99	IC CXP101064-202R-T6
R527	1-216-821-91	RES, CHIP 1.0K (1608)

Ref.	Part No.	Description
for SCPH-30003/-30004 GH010-64MR		

C408	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C526	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C543	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
IC403	6-700-234-01	IC BD3992F-E2
IC505	6-800-196-01	IC TC5364200FT-PA06
IC518	8-759-680-49	IC TC7WB125FK(TE85R)
IC604	8-752-921-99	IC CXP101064-202R-T6
R527	1-216-821-91	RES, CHIP 1.0K (1608)
for IC801 : SP3727ACA0PMR(8-7529-685-15)		

C632	1-107-826-91	CAP, CHIP CERAMIC 100000PF
C689	1-162-968-91	CAP, CHIP CERAMIC 100000PF
IC606	8-759-712-38	IC HD74HC1G66CME
IC606	8-759-712-63	IC MC74VHC1G66DFT1
IC801	8-7529-685-15	IC SP3727ACA0PMR
R640	1-216-837-91	RES, CHIP 22K (1608)
R643	1-216-850-91	RES, CHIP 270K (1608)
for IC801:SP3727AFA0PMR(6-700-585-01)		

IC801	6-700-585-01	IC SP3727AFA0PMR
R640	1-216-864-91	CONDUCTOR, CHIP(1608)

Common Parts

<CAPACITOR>		
C101	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C102	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C103	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C104	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C105	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C106	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C107	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C108	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C109	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C110	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C111	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C112	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C113	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C114	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C115	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C116	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C117	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C118	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C119	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C120	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C121	1-107-826-91	CAP, CHIP CERAMIC 100000PF B

Ref.	Part No.	Description
C122	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C123	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C124	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C125	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C126	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C127	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C128	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C129	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C131	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C132	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C134	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C135	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C136	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C137	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C138	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C139	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C140	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C141	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF
C142	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C143	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C144	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C145	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C146	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C147	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C148	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C149	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C150	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C151	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C152	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C153	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C154	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C155	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C156	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C157	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C158	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C159	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C160	1-162-925-91	CAP, CERAMIC 68PF CH (1608)
C161	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C162	1-162-925-91	CAP, CERAMIC 68PF CH (1608)
C163	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C164	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C168	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C169	1-164-874-81	CAP, CHIP CERAMIC 100PF CH (1005)
C170	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C175	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C176	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C212	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C213	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C214	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C215	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C216	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C217	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C218	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C219	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C220	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C221	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C222	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C223	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C224	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C225	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C226	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C227	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C228	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C229	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C230	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C231	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)

Ref.	Part No.	Description
C232	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C233	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C234	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C235	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C236	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C237	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C238	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C239	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C240	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C241	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C242	1-128-707-22	CAP, TANTALUM ELECT (SMD) 220
C243	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF
C244	1-128-707-22	CAP, TANTALUM ELECT (SMD) 220
C245	1-128-707-22	CAP, TANTALUM ELECT (SMD) 220
C247	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C248	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C249	1-115-156-91	CAP, CERAMIC 1000000PF F (1608)
C250	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C252	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C254	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C255	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C256	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C257	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C261	1-128-004-21	CAP, ELECT (CHIP) 10MF
C262	1-128-004-21	CAP, ELECT (CHIP) 10MF
C263	1-128-004-21	CAP, ELECT (CHIP) 10MF
C265	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)
C266	1-128-004-21	CAP, ELECT (CHIP) 10MF
C267	1-126-210-21	CAP, ELECT 220MF
C268	1-126-210-21	CAP, ELECT 220MF
C269	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C270	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C271	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C272	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C275	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C276	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C277	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C278	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C279	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C281	1-115-156-91	CAP, CERAMIC 1000000PF F (1608)
C282	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C283	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C285	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C286	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C287	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C288	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C289	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C290	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C291	1-164-862-81	CAP, CHIP CERAMIC 33PF CH (1005)
C292	1-107-725-91	CAP, CERAMIC 100000PF B (2012)
C293	1-137-765-21	CAP, ELECT 47MF
C294	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C295	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C296	1-126-210-21	CAP, ELECT 220MF
C297	1-126-210-21	CAP, ELECT 220MF
C298	1-126-210-21	CAP, ELECT 220MF
C301	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C302	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C303	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C304	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C305	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C306	1-164-387-91	CAP, CERAMIC 240PF CH (1608)
C307	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C308	1-165-112-91	CAP, CERAMIC 330000PF F (1608)
C309	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C310	1-162-970-91	CAP, CERAMIC 10000PF B (1608)

Ref.	Part No.	Description
C311	1-162-916-91	CAP, CERAMIC 12PF CH (1608)
C312	1-162-917-91	CAP, CERAMIC 15PF CH (1608)
C313	1-162-910-91	CAP, CERAMIC 5.0PF CH (1608)
C314	1-162-910-91	CAP, CERAMIC 5.0PF CH (1608)
C315	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C316	1-165-112-91	CAP, CERAMIC 330000PF F (1608)
C317	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C318	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C319	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C320	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C321	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C322	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C323	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C324	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C325	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C326	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C327	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C328	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C329	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C330	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C331	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C332	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C333	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C334	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C335	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C336	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C337	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C338	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C339	1-125-764-61	CAP, CHIP CERAMIC 100PF CH (1608)
C340	1-125-764-61	CAP, CHIP CERAMIC 100PF CH (1608)
C341	1-125-764-61	CAP, CHIP CERAMIC 100PF CH (1608)
C342	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C343	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C344	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C345	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C355	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C356	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C363	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C364	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C365	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C366	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C367	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C368	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C369	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C370	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C371	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C372	1-165-492-21	CAP, ELECT 100MF (1608)
C373	1-165-492-21	CAP, ELECT 100MF (1608)
C401	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C402	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)
C403	1-164-937-81	CAP, CHIP CERAMIC 1000PF B (1005)
C404	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C405	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C407	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C409	1-162-969-91	CAP, CERAMIC 6800PF B (1608)
C410	1-162-969-91	CAP, CERAMIC 6800PF B (1608)
C414	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C415	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C416	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C417	1-164-379-91	CAP, CERAMIC 43PF CH (1608)
C418	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C419	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C420	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C421	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF (1608)
C422	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C423	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)

Ref.	Part No.	Description
C424	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF (1608)
C425	1-124-779-21	CAP, ELECT 10MF (1608)
C426	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C430	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C431	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C432	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)
C433	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)
C434	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C435	1-115-566-91	CAP, CERAMIC 4.7MF B (1608)
C437	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C438	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C439	1-135-593-21	CAP, ELECT 150MF (1608)
C440	1-135-592-21	CAP, ELECT 100MF (1608)
C441	1-135-593-21	CAP, ELECT 150MF (1608)
C443	1-135-592-21	CAP, ELECT 100MF (1608)
C444	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)
C446	1-135-592-21	CAP, ELECT 100MF (2012)
C447	1-107-682-91	CAP, CERAMIC 1000000PF B (3216)
C449	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C450	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C452	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C453	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C455	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF (1608)
C456	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C457	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C458	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C460	1-164-174-91	CAP, CERAMIC 8200PF B (1608)
C461	1-164-174-91	CAP, CERAMIC 8200PF B (1608)
C462	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)
C465	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C466	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C467	1-126-209-21	CAP, ELECT 100MF (1608)
C468	1-126-209-21	CAP, ELECT 100MF (1608)
C469	1-162-977-91	CAP, CERAMIC 1800PF B (1608)
C470	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C471	1-164-379-91	CAP, CERAMIC 43PF CH (1608)
C472	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C473	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C474	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C475	1-164-730-91	CAP, CERAMIC 1200PF B (1608)
C476	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)
C477	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C478	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C479	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C480	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)
C482	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C483	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C485	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C486	1-137-765-21	CAP, ELECT 47MF (1608)
C487	1-131-999-21	CAP, SOLID ELECT 150MF (1608)
C488	1-115-566-91	CAP, CERAMIC 4.7MF B (1608)
C489	1-131-999-21	CAP, SOLID ELECT 150MF (1608)
C490	1-126-209-21	CAP, ELECT 100MF (1608)
C491	1-126-209-21	CAP, ELECT 100MF (1608)
C492	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C493	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C494	1-107-725-91	CAP, CERAMIC 100000PF B (2012)
C495	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C496	1-107-682-91	CAP, CERAMIC 1000000PF B (3216)
C497	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C498	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C499	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)
C501	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)
C502	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C503	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)

Ref.	Part No.	Description
C504	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)
C507	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)
C508	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C509	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C510	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C513	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C514	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C516	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C517	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C518	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C521	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C522	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C523	1-107-726-91	CAP, CHIP CERAMIC 10000PF B (1608)
C524	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C525	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C527	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C528	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C529	1-128-008-21	CAP, ELECT (CHIP) 3.3MF (1608)
C530	1-128-008-21	CAP, ELECT (CHIP) 3.3MF (1608)
C533	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C534	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C535	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C536	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C537	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C538	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C539	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C540	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C541	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C542	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C544	1-137-765-21	CAP, ELECT 47MF (1608)
C545	1-137-765-21	CAP, ELECT 47MF (1608)
C601	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C603	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C605	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C606	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C607	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)
C609	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C623	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C624	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C625	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C629	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C630	1-164-173-91	CAP, CERAMIC 3900PF B (1608)
C631	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)
C633	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C634	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C635	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)
C636	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C637	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C638	1-107-726-91	CAP, CHIP CERAMIC 100000PF B (1608)
C639	1-164-217-91	CAP, CERAMIC 150PF CH (1608)
C640	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF (1608)
C642	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C643	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C644	1-164-230-91	CAP, CERAMIC 220PF CH (1608)
C645	1-165-176-91	CAP, CERAMIC 47000PF B (1608)
C646	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C647	1-117-863-91	CAP, CHIP CERAMIC 0.47MF B (1608)
C648	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C649	1-107-726-91	CAP, CHIP CERAMIC 10000PF B (1608)
C650	1-164-230-91	CAP, CERAMIC 220PF CH (1608)
C651	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C652	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C653	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C654	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C655	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF (1608)
C656	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)

Ref.	Part No.	Description
C657	1-164-230-91	CAP, CERAMIC 220PF CH (1608)
C658	1-164-230-91	CAP, CERAMIC 220PF CH (1608)
C660	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C661	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C662	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C664	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF (1608)
C665	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C666	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C667	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C668	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C671	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C672	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C673	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C674	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C675	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C676	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)
C685	1-117-863-91	CAP, CHIP CERAMIC 0.47MF B (1608)
C688	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C693	1-162-912-91	CAP, CERAMIC 7.0PF CH (1608)
C701	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C702	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C703	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C704	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C705	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C706	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C707	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C708	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C709	1-127-692-91	CAP, CHIP CERAMIC 10MF B (32

Ref.	Part No.	Description
C826	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C827	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C828	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C829	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C830	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C831	1-162-975-91	CAP, CERAMIC 24PF CH (1608)
C832	1-115-467-91	CAP, CHIP CERAMIC0.22MF B (1608)
C834	1-163-038-91	CAP, CERAMIC 100000PF F (2012)
C835	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C836	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C837	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C839	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C840	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C841	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C842	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C843	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C844	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C845	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C846	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (2012)
C848	1-107-823-91	CAP, CERAMIC 470000PF B (2012)
C850	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C851	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C853	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C854	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C855	1-115-467-91	CAP, CHIP CERAMIC0.22MF B (1608)
C857	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C859	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C860	1-164-173-91	CAP, CERAMIC 3900PF B (1608)
C862	1-164-739-91	CAP, CERAMIC 560PF CH (1608)
C863	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C866	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C868	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C869	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C870	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C871	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C872	1-115-467-91	CAP, CHIP CERAMIC0.22MF B (1608)
C873	1-164-392-91	CAP, CERAMIC 390PF CH (1608)
C874	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C875	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (2012)
C876	1-125-838-91	CAP, CHIP CERAMIC2.2MF B (1608)
C877	1-164-173-91	CAP, CERAMIC 3900PF B (1608)
C879	1-164-739-91	CAP, CERAMIC 560PF CH (1608)
C880	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C882	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C883	1-163-038-91	CAP, CERAMIC 100000PF F (2012)
C888	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C889	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C890	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF (1608)
C891	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C895	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C897	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C898	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C899	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C901	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C902	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C903	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C904	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C905	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C906	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C907	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C908	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C909	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C910	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C911	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C912	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C913	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)

Ref.	Part No.	Description
C914	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C915	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C916	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C917	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C918	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C919	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C920	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C921	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C922	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C923	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C924	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C925	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C926	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C927	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C928	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C929	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C930	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C931	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C932	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C933	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C934	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C935	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C936	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C937	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C938	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C939	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C940	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C941	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C942	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C943	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C944	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C945	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C946	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C947	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C948	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C949	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C950	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C951	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C952	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C953	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C954	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C955	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C956	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C957	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C958	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C959	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C960	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C961	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C962	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C963	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C965	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C966	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C967	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C968	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C980	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C981	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C982	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C983	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C984	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C985	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C986	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C987	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C988	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C989	1-107-826-91	CAP, CHIP CERAMIC 100000PF B (1608)
C990	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)

Ref.	Part No.	Description
		<CONNECTOR>
CN201	1-815-631-11	CONNECTOR, SQUARE TYPE 12P
CN302	1-794-206-21	CONNECTOR, FFC/FPC (ZIF) 36P
CN303	1-694-822-11	TERMINAL BOARD (LINK/USB)
CN401	1-815-630-11	PIN, CONNECTOR 4P
CN402	1-815-648-21	PIN, CONNECTOR (PC BOARD)
CN403	1-784-650-21	CONNECTOR 2P
CN406	1-815-653-21	CONNECTOR, FFC/FPC (ZIF) 7P
CN501	1-476-736-11	TRANSMITTER UNIT, LIGHT
CN504	1-815-632-11	CONNECTOR BOARD TO BOARD 110P
CN801	1-794-237-21	CONNECTOR, FFC/FPC 30P
CN802	1-770-619-41	PIN, CONNECTOR 2P
CN803	1-779-206-21	CONNECTOR, FFC (LIF(NON-ZIF)) 4P
CN804	1-794-194-21	CONNECTOR, FFC/FPC 13P
CN805	1-770-619-21	PIN, CONNECTOR 2P
CN806	1-770-619-81	PIN, CONNECTOR 2P
		<NETWORK>
CP201	1-234-605-21	NETWORK, RC
		<DIODE>
D201	8-719-065-78	DIODE MAZF12000LS0
D202	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D203	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D204	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D205	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D206	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D208	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D209	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D210	8-719-064-61	DIODE 01BZA8.2 (TE85L)
D301	8-719-071-87	DIODE MA785-(TX),SO
D302	8-719-071-87	DIODE MA785-(TX),SO
D402	8-719-074-34	DIODE RB495D-T146
D403	8-719-074-34	DIODE RB495D-T146
D404	8-719-033-15	DIODE HN2D02FU-TE85R
D405	8-719-078-04	DIODE EC31QS03L-TE12L
D407	8-719-074-34	DIODE RB495D-T146
D408	8-719-074-34	DIODE RB495D-T146
D500	8-719-941-21	DIODE DAP202UT106
D501	8-719-082-76	DIODE CL-201TLY-C-TU
D801	8-719-065-68	DIODE MAZF04700LS0
D802	8-719-065-68	DIODE MAZF04700LS0
		<FUSE>
△ F001	1-576-434-21	FUSE, CHIP
△ F003	1-576-434-21	FUSE, CHIP
		<FERRITE BEAD>
FB102	1-469-667-21	FERRITE, EMI (SMD)
FB103	1-469-667-21	FERRITE, EMI (SMD)
FB201	1-414-813-21	FERRITE, EMI (SMD)
FB202	1-500-113-22	BEAD, FERRITE (CHIP)
FB203	1-500-113-22	BEAD, FERRITE (CHIP)
FB204	1-500-113-22	BEAD, FERRITE (CHIP)
FB205	1-500-113-22	BEAD, FERRITE (CHIP)
FB206	1-500-113-22	BEAD, FERRITE (CHIP)
FB303	1-414-555-21	FERRITE, EMI (SMD)
FB304	1-414-555-21	FERRITE, EMI (SMD)
FB305	1-414-555-21	FERRITE, EMI (SMD)
FB306	1-414-555-21	FERRITE, EMI (SMD)
FB307	1-414-555-21	FERRITE, EMI (SMD)
FB308	1-414-555-21	FERRITE, EMI (SMD)
FB309	1-414-555-21	FERRITE, EMI (SMD)
FB310	1-414-555-21	FERRITE, EMI (SMD)
FB311	1-414-555-21	FERRITE, EMI (SMD)

Ref.	Part No.	Description
FB312	1-414-555-21	FERRITE, EMI (SMD)
FB313	1-469-324-21	FERRITE, EMI (SMD)
FB314	1-469-324-21	FERRITE, EMI (SMD)
FB315	1-469-324-21	FERRITE, EMI (SMD)
FB316	1-469-324-21	FERRITE, EMI (SMD)
FB317	1-469-110-21	FERRITE, EMI (SMD)
FB318	1-469-110-21	FERRITE, EMI (SMD)
FB319	1-469-110-21	FERRITE, EMI (SMD)
FB320	1-469-110-21	FERRITE, EMI (SMD)
FB321	1-469-110-21	FERRITE, EMI (SMD)
FB322	1-469-110-21	FERRITE, EMI (SMD)
FB323	1-469-110-21	FERRITE, EMI (SMD)
FB324	1-469-110-21	FERRITE, EMI (SMD)
FB403	1-469-667-21	FERRITE, EMI (SMD)
FB404	1-469-667-21	FERRITE, EMI (SMD)
FB405	1-469-667-21	FERRITE, EMI (SMD)
FB406	1-469-667-21	FERRITE, EMI (SMD)
FB407	1-469-667-21	FERRITE, EMI (SMD)
FB408	1-469-667-21	FERRITE, EMI (SMD)
FB801	1-469-562-21	FERRITE, EMI (SMD)
FB802	1-469-562-21	FERRITE, EMI (SMD)
<FILTER>		
FL201	1-469-991-21	EMI FILTER (SMD)
FL202	1-469-991-21	EMI FILTER (SMD)
FL203	1-469-991-21	EMI FILTER (SMD)
FL301	1-234-601-21	NETWORK, RC (USB)
FL302	1-234-601-21	NETWORK, RC (USB)
<IC>		
IC101	8-759-831-20	IC CY2212ZC-2T
IC101	8-759-834-04	IC SN104971APWR
IC102	6-800-080-01	IC TC59RM716GB-8DYELZ
IC102	8-759-666-89	IC TC59RM716GB-8(YEL
IC102	8-759-837-33	IC K4R271669A-SCK8T00
IC103	6-800-080-01	IC TC59RM716GB-8DYELZ
IC103	8-759-666-89	IC TC59RM716GB-8(YEL
IC103	8-759-837-33	IC K4R271669A-SCK8T00
IC104	8-759-699-09	IC CXD9615GB
IC105	8-759-689-90	IC LM74C1MX-3
IC202	8-759-699-08	IC CXD2944GB
IC205	6-700-230-01	IC SC44728BPBEB
IC206	8-752-093-56	IC CXA3525R-T4
IC206	8-752-099-53	IC CXA3525BR-T4
IC207	8-759-391-69	IC MC78M05CDTRK
IC207	8-759-691-00	IC JCP78M05CDTRK
IC207	8-759-697-61	IC L78M05CDT-TR(P)
IC208	8-759-683-81	IC SN74CBT1G125DCKR
IC209	8-759-697-60	IC MM3071CFBE
IC303	8-759-699-11	IC CXD9619GB
IC305	6-700-119-01	IC T5NB8(YEL)
IC306	8-759-688-07	IC MM3051NULE
IC306	8-759-697-24	IC S-817A12ANB-CUB-T2
IC401	8-759-661-25	IC S-80769SN-J0-T1
IC402	8-759-837-34	IC TMP87C807U-2A69(EL)
IC403	6-700-234-01	IC BD3992F-E2
IC403	8-759-688-08	IC MM1537DFBE
IC404	8-759-689-89	IC SN104809DBTR
IC405	8-759-560-17	IC RS5C348A-E2
IC406	8-759-698-67	IC BR2880F-E2
IC407	8-759-712-66	IC PQ018PZ01ZP
IC408	8-759-712-65	IC PQ070XZ01ZP
IC409	8-759-689-89	IC SN104809DBTR
IC410	8-749-018-42	IC SI-30261LSA-TL
IC411	8-759-688-06	IC MM3031JULE
IC412	8-749-018-41	IC SI-3025LSA-TL

Ref.	Part No.	Description
IC413	6-700-233-01	IC MM1573ZNLE
IC413	8-759-598-12	IC LP2985IM5X-3.5
IC414	8-759-069-41	IC TA7808F(Te16L)
IC414	8-759-473-16	IC BA17808FP-E2
IC414	8-759-697-62	IC NJM7808DL1A(Te1)
IC415	8-759-581-11	IC NJM2125F(Te2)
IC501	6-700-231-01	IC CXD9611AR
IC501	8-759-699-10	IC CXD9611R
IC502	8-759-712-79	IC K4E151612D-TL50T00
IC502	8-759-712-80	IC MT4LC1M16E5TG-5TR
IC502	8-759-712-81	IC GM71V18163CT-5
IC502	8-759-712-82	IC SDMV18165CTM6S
IC503	6-800-197-01	IC MR27V3202F-A7TPZ
IC504	8-752-408-53	IC CXD2942AR
IC504	8-752-410-55	IC CXD2942BR
IC517	8-759-667-10	IC CS4335-KS
IC603	8-759-370-11	IC NJM2100V-TE2
IC605	8-752-413-11	IC CXD1869BQ
IC802	8-759-697-65	IC BA5815FM-E2
IC803	8-759-588-60	IC BA6664FM-E2
IC805	8-759-712-38	IC HD74HC1G66CME
IC805	8-759-712-63	IC MC74VHC1G66DFT1
IC806	8-759-337-40	IC NJM2904V(Te2)
IC807	8-759-391-69	IC MC78M05CDTRK
IC807	8-759-691-00	IC JCP78M05CDTRK
IC807	8-759-697-61	IC L78M05CDT-TR(P)
<INDUCTOR>		
L102	1-414-398-41	INDUCTOR (SMD) 10.0UH
L203	1-469-967-21	INDUCTOR, CHIP 10UH
L205	1-469-967-21	INDUCTOR, CHIP 10UH
L206	1-412-960-21	INDUCTOR, SMALL TYPE 56UH
L401	1-411-197-21	COIL, DD CONVERTER
L404	1-419-905-21	COIL, CHOKE (SMD) 1.82UH
L408	1-419-898-21	COIL, CHOKE 5.6UH
L410	1-411-197-21	COIL, DD CONVERTER
L411	1-424-789-21	COIL, CHOKE (SMD) 10UH
L412	1-411-197-21	COIL, DD CONVERTER
L413	1-424-789-21	COIL, CHOKE (SMD) 10UH
L414	1-424-789-21	COIL, CHOKE (SMD) 10UH
L801	1-469-524-91	INDUCTOR 4.7UH (NLFV25)
L802	1-469-524-91	INDUCTOR 4.7UH (NLFV25)
L803	1-414-394-41	INDUCTOR (SMD) 2.2UH
<COIL>		
LF101	1-419-100-21	COIL, COMMON-MODE CHOKE
LF801	1-416-405-21	FILTER, CHIP EMI (COMMON MODE)
<LINK>		
△ PS001	1-576-519-21	FUSE, MICRO
△ PS002	1-533-940-21	RINK, CHIP IC
△ PS003	1-533-940-21	RINK, CHIP IC
△ PS004	1-533-940-21	RINK, CHIP IC
△ PS006	1-533-915-41	RINK, CHIP IC
△ PS007	1-533-282-21	LINK, IC
△ PS008	1-533-940-21	RINK, CHIP IC
△ PS009	1-533-915-41	RINK, CHIP IC
△ PS010	1-533-282-21	LINK, IC
△ PS011	1-576-519-21	FUSE, MICRO
△ PS012	1-533-915-41	RINK, CHIP IC
△ PS013	1-533-940-21	RINK, CHIP IC
△ PS014	1-533-282-21	LINK, IC
△ PS015	1-533-915-41	RINK, CHIP IC
<TRANSISTOR>		
Q201	8-729-026-50	TRANSISTOR 2SA1037AK-T146-QR

Ref.	Part No.	Description
Q204	8-729-049-77	TRANSISTOR HN1B01F-GR (T5LSONY)
Q205	8-729-013-22	TRANSISTOR HN1A01FU-TE85R
Q401	8-729-055-58	TRANSISTOR SI4894DY-T1
Q402	8-729-053-80	TRANSISTOR SI4830DY-T1
Q404	8-729-052-07	TRANSISTOR HAT2064R-EL
Q405	8-729-427-47	TRANSISTOR XP4213-TXE
Q406	8-729-053-80	TRANSISTOR SI4830DY-T1
Q407	8-729-046-04	TRANSISTOR FDS6690A
Q408	8-729-051-61	TRANSISTOR IRF7807D1-TR
Q409	8-729-427-47	TRANSISTOR XP4213-TXE
Q410	8-729-013-97	TRANSISTOR RN1304-TE85L
Q411	8-729-043-74	TRANSISTOR SI4435DY-T1-REVA
Q412	8-729-043-74	TRANSISTOR SI4435DY-T1-REVA
Q413	8-729-054-34	TRANSISTOR FDN304P
Q414	8-729-043-74	TRANSISTOR SI4435DY-T1-REVA
Q415	8-729-052-41	TRANSISTOR 2SC4541 (2TL SONY1)
Q505	8-729-021-09	TRANSISTOR RN4904 (TE85R)
Q506	8-729-056-15	TRANSISTOR IMH20T108
Q600	8-729-016-26	TRANSISTOR 2SK1958-T1
Q603	8-729-017-33	TRANSISTOR RN1706-TE85R
Q801	8-729-031-35	TRANSISTOR 2SK2034-TE85L
Q802	8-729-029-13	TRANSISTOR DTC143ZUA-T106
Q803	8-729-031-35	TRANSISTOR 2SK2034-TE85L
Q804	8-729-103-96	TRANSISTOR 2SB798-T1DL
Q805	8-729-103-96	TRANSISTOR 2SB798-T1DL
Q806	8-729-048-50	TRANSISTOR 2SK3018-T106
Q808	8-729-048-50	TRANSISTOR 2SK3018-T106
Q810	8-729-048-50	TRANSISTOR 2SK3018-T106
Q814	8-729-029-13	TRANSISTOR DTC143ZUA-T106
<RESISTOR>		
R101	1-220-884-81	RES, CHIP 39
R102	1-208-866-81	RES, CHIP 130
R103	1-220-884-81	RES, CHIP 39
R104	1-208-866-81	RES, CHIP 130
R105	1-216-864-91	CONDUCTOR, CHIP
R106	1-216-809-91	RES, CHIP 100
R107	1-216-809-91	RES, CHIP 100
R109	1-218-961-81	RES, CHIP 4.7K
R110	1-211-983-91	RES, CHIP 39
R111	1-211-983-91	RES, CHIP 39
R112	1-211-989-91	RES, CHIP 68
R113	1-211-989-91	RES, CHIP 68
R114	1-211-983-91	RES, CHIP 39
R115	1-211-983-91	RES, CHIP 39
R116	1-211-983-91	RES, CHIP 39
R117	1-211-983-91	RES, CHIP 39
R118	1-211-973-91	RES, CHIP 15
R119	1-211-973-91	RES, CHIP 15
R120	1-211-973-91	RES, CHIP 15
R121	1-211-973-91	RES, CHIP 15
R122	1-216-864-91	CONDUCTOR, CHIP
R123	1-218-990-81	CONDUCTOR, CHIP
R124	1-216-864-91	CONDUCTOR, CHIP
R125	1-218-990-81	CONDUCTOR, CHIP
R126	1-216-833-91	RES, CHIP 10K
R127	1-216-829-91	RES, CHIP 4.7K
R128	1-216-829-91	RES, CHIP 4.7K
R129	1-216-821-91	RES, CHIP 1.0K
R130	1-216-817-91	RES, CHIP 470
R131	1-216-833-91	RES, CHIP 10K
R132	1-216-833-91	RES, CHIP 10K
R133	1-216-833-91	RES, CHIP 10K
R134	1-218-965-81	RES, CHIP 10K
R135	1-216-864-91	CONDUCTOR, CHIP
R136	1-216-864-91	CONDUCTOR, CHIP

Ref.	Part No.	Description
R138	1-216-864-91	CONDUCTOR, CHIP
R139	1-216-801-91	RES, CHIP 22
R145	1-218-953-81	RES, CHIP 1.0K
R146	1-216-821-91	RES, CHIP 1.0K
R147	1-216-821-91	RES, CHIP 1.0K
R185	1-216-829-91	RES, CHIP 4.7K
R188	1-216-829-91	RES, CHIP 4.7K
R196	1-218-933-81	RES, CHIP 22
R202	1-216-833-91	RES, CHIP 10K
R203	1-216-864-91	CONDUCTOR, CHIP
R205	1-216-864-91	CONDUCTOR, CHIP
R208	1-216-864-91	CONDUCTOR, CHIP
R212	1-216-864-91	CONDUCTOR, CHIP
R213	1-216-864-91	CONDUCTOR, CHIP
R216	1-216-809-91	RES, CHIP 100
R217	1-218-859-91	RES, CHIP 3.3K
R218	1-218-847-91	RES, CHIP 1.0K
R219	1-218-851-91	RES, CHIP 1.5K
R220	1-218-933-81	RES, CHIP 22
R225	1-216-833-91	RES, CHIP 10K
R226	1-218-965-81	RES, CHIP 10K
R227	1-216-864-91	CONDUCTOR, CHIP
R228	1-218-965-81	RES, CHIP 10K
R233	1-216-821-91	RES, CHIP 1.0K
R236	1-216-809-91	RES, CHIP 100
R237	1-216-829-91	RES, CHIP 4.7K
R244	1-218-831-91	RES, CHIP 220
R245	1-218-831-91	RES, CHIP 220
R246	1-218-831-91	RES, CHIP 220
R247	1-216-801-91	RES, CHIP 22
R251	1-216-837-91	RES, CHIP 22K
R252	1-216-839-91	RES, CHIP 33K
R253	1-216-833-91	RES, CHIP 10K
R257	1-216-824-91	RES, CHIP 1.8K
R258	1-208-923-81	RES, CHIP 33K
R259	1-216-824-91	RES, CHIP 1.8K
R261	1-218-961-81	RES, CHIP 4.7K
R263	1-216-825-91	RES, CHIP 2.2K
R264	1-216-821-91	RES, CHIP 1.0K
R265	1-216-821-91	RES, CHIP 1.0K
R270	1-218-853-91	RES, CHIP 1.8K
R272	1-218-859-91	RES, CHIP 3.3K
R273	1-218-851-91	RES, CHIP 1.5K
R277	1-218-853-91	RES, CHIP 1.8K
R278	1-218-859-91	RES, CHIP 3.3K
R279	1-218-851-91	RES, CHIP 1.5K
R292	1-216-833-91	RES, CHIP 10K
R294	1-216-829-91	RES, CHIP 4.7K
R295	1-216-817-91	RES, CHIP 470
R307	1-208-857-81	RES, CHIP 56
R308	1-208-904-81	RES, CHIP 5.1K
R309	1-211-987-91	RES, CHIP 56
R310	1-211-987-91	RES, CHIP 56
R311	1-216-829-91	RES, CHIP 4.7K
R312	1-208-857-81	RES, CHIP 56
R315	1-218-866-91	RES, CHIP 6.2K
R316	1-216-797-91	RES, CHIP 10
R318	1-218-990-81	CONDUCTOR, CHIP
R320	1-219-570-91	RES, CHIP 10M
R321	1-216-813-91	RES, CHIP 220
R322	1-216-857-91	RES, CHIP 1.0M
R324	1-216-833-91	RES, CHIP 10K
R327	1-216-833-91	RES, CHIP 10K
R328	1-216-841-91	RES, CHIP 47K
R329	1-216-805-91	RES, CHIP 47
R330	1-211-973-91	RES, CHIP 15

Ref.	Part No.	Description
R331	1-216-805-91	RES, CHIP 47
R332	1-216-817-91	RES, CHIP 470
R333	1-216-817-91	RES, CHIP 470
R334	1-216-829-91	RES, CHIP 4.7K
R335	1-216-829-91	RES, CHIP 4.7K
R336	1-216-821-91	RES, CHIP 1.0K
R347	1-211-986-91	RES, CHIP 51
R349	1-216-821-91	RES, CHIP 1.0K
R350	1-216-807-91	RES, CHIP 68
R351	1-216-805-91	RES, CHIP 47
R352	1-216-797-91	RES, CHIP 10
R353	1-216-801-91	RES, CHIP 22
R354	1-216-801-91	RES, CHIP 22
R357	1-218-933-81	RES, CHIP 22
R358	1-216-801-91	RES, CHIP 22
R359	1-216-801-91	RES, CHIP 22
R360	1-218-937-81	RES, CHIP 47
R361	1-218-937-81	RES, CHIP 47
R362	1-216-805-91	RES, CHIP 47
R363	1-216-864-91	CONDUCTOR, CHIP
R364	1-216-805-91	RES, CHIP 47
R365	1-216-805-91	RES, CHIP 47
R366	1-218-937-81	RES, CHIP 47
R367	1-216-805-91	RES, CHIP 47
R368	1-216-805-91	RES, CHIP 47
R394	1-216-833-91	RES, CHIP 10K
R395	1-218-957-81	RES, CHIP 2.2K
R401	1-218-969-81	RES, CHIP 22K
R402	1-216-837-91	RES, CHIP 22K
R403	1-216-849-91	RES, CHIP 220K
R404	1-216-845-91	RES, CHIP 100K
R405	1-216-845-91	RES, CHIP 100K
R406	1-216-811-91	RES, CHIP 150
R407	1-216-811-91	RES, CHIP 150
R408	1-216-839-91	RES, CHIP 33K
R409	1-216-864-91	CONDUCTOR, CHIP
R410	1-218-883-91	RES, CHIP 33K
R411	1-218-883-91	RES, CHIP 33K
R412	1-218-883-91	RES, CHIP 33K
R413	1-218-883-91	RES, CHIP 33K
R414	1-216-864-91	CONDUCTOR, CHIP
R415	1-216-839-91	RES, CHIP 33K
R416	1-216-839-91	RES, CHIP 33K
R417	1-216-813-91	RES, CHIP 220
R418	1-216-817-91	RES, CHIP 470
R419	1-216-833-91	RES, CHIP 10K
R420	1-216-833-91	RES, CHIP 10K
R421	1-216-790-91	RES, CHIP 2.7
R422	1-216-797-91	RES, CHIP 10
R423	1-216-790-91	RES, CHIP 2.7
R424	1-216-797-91	RES, CHIP 10
R426	1-218-879-91	RES, CHIP 22K
R427	1-218-871-91	RES, CHIP 10K
R428	1-216-309-91	RES, CHIP 5.6
R429	1-216-833-91	RES, CHIP 10K
R430	1-216-813-91	RES, CHIP 220
R431	1-216-813-91	RES, CHIP 220
R432	1-216-829-91	RES, CHIP 4.7K
R433	1-216-829-91	RES, CHIP 4.7K
R434	1-216-810-91	RES, CHIP 120
R435	1-216-810-91	RES, CHIP 120
R438	1-218-850-91	RES, CHIP 1.3K
R439	1-218-857-91	RES, CHIP 2.7K
R440	1-218-859-91	RES, CHIP 3.3K
R441	1-218-879-91	RES, CHIP 22K
R442	1-218-869-91	RES, CHIP 8.2K

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description		
R443	1-218-865-91	RES, CHIP 5.6K	(1608)	R649	1-216-833-91 RES, CHIP 10K	(1608)	R870	1-216-849-91 RES, CHIP 220K	(1608)	RB318	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
R444	1-218-881-91	RES, CHIP 27K	(1608)	R650	1-216-833-91 RES, CHIP 10K	(1608)				RB319	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
R445	1-218-849-91	RES, CHIP 1.2K	(1608)				R871	1-218-896-91 RES, CHIP 110K	(1608)	RB320	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
				R651	1-216-835-91 RES, CHIP 15K	(1608)	R872	1-216-844-91 RES, CHIP 82K	(1608)				
R446	1-216-817-91	RES, CHIP 470	(1608)	R653	1-216-845-91 RES, CHIP 100K	(1608)	R873	1-216-839-91 RES, CHIP 33K	(1608)	RB321	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
R447	1-216-817-91	RES, CHIP 470	(1608)	R654	1-216-845-91 RES, CHIP 100K	(1608)	R874	1-216-828-91 RES, CHIP 3.9K	(1608)	RB322	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
R448	1-218-965-81	RES, CHIP 10K		R657	1-216-839-91 RES, CHIP 33K	(1608)	R875	1-216-023-91 RES, CHIP 82	(2012)	RB323	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
R449	1-216-833-91	RES, CHIP 10K	(1608)	R658	1-216-833-91 RES, CHIP 10K	(1608)				RB324	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
R450	1-216-817-91	RES, CHIP 470	(1608)				R876	1-216-023-91 RES, CHIP 82	(2012)	RB325	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
				R660	1-216-833-91 RES, CHIP 10K	(1608)	R877	1-216-023-91 RES, CHIP 82	(2012)				
R451	1-218-949-81	RES, CHIP 470		R661	1-216-833-91 RES, CHIP 10K	(1608)	R878	1-216-023-91 RES, CHIP 82	(2012)	RB326	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
R452	1-216-797-91	RES, CHIP 10	(1608)	R667	1-216-861-91 RES, CHIP 2.2M	(1608)	R879	1-216-023-91 RES, CHIP 82	(2012)	RB327	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R453	1-216-797-91	RES, CHIP 10	(1608)	R668	1-216-853-91 RES, CHIP 470K	(1608)	R880	1-216-023-91 RES, CHIP 82	(2012)	RB328	1-233-414-21 RES, CHIP NETWORK 4.7K	(3216)	
R454	1-216-797-91	RES, CHIP 10	(1608)	R669	1-216-845-91 RES, CHIP 100K	(1608)				RB329	1-233-783-91 RES, NETWORK 22	(1608)	
R455	1-216-845-91	RES, CHIP 100K	(1608)				R881	1-216-023-91 RES, CHIP 82	(2012)	RB402	1-233-803-91 RES, NETWORK 1.5K	(1608)	
				R670	1-216-833-91 RES, CHIP 10K	(1608)	R882	1-216-023-91 RES, CHIP 82	(2012)				
R456	1-216-821-91	RES, CHIP 1.0K	(1608)	R671	1-216-827-91 RES, CHIP 3.3K	(1608)	R901	1-218-937-81 RES, CHIP 47		RB403	1-233-789-91 RES, NETWORK 10K	(1608)	
R457	1-218-887-91	RES, CHIP 47K	(1608)	R672	1-218-888-91 RES, CHIP 51K	(1608)	R902	1-218-937-81 RES, CHIP 47		RB405	1-233-803-91 RES, NETWORK 1.5K	(1608)	
R458	1-216-797-91	RES, CHIP 10	(1608)	R673	1-216-827-91 RES, CHIP 3.3K	(1608)	R974	1-216-801-91 RES, CHIP 22	(1608)	RB406	1-233-792-91 RES, NETWORK 100K	(1608)	
R459	1-216-833-91	RES, CHIP 10K	(1608)	R674	1-216-845-91 RES, CHIP 100K	(1608)				RB407	1-233-795-91 RES, NETWORK 1.0M	(1608)	
R460	1-218-871-91	RES, CHIP 10K	(1608)				R975	1-216-801-91 RES, CHIP 22	(1608)	RB408	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
				R675	1-216-839-91 RES, CHIP 33K	(1608)	R984	1-216-864-91 CONDUCTOR, CHIP	(1608)				
R461	1-216-309-91	RES, CHIP 5.6	(2012)	R678	1-216-829-91 RES, CHIP 4.7K	(1608)				RB409	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R463	1-216-857-91	RES, CHIP 1.0M	(1608)	R689	1-216-845-91 RES, CHIP 100K	(1608)	RB101	1-234-496-21 ARRAY, RESISTOR 39		RB410	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R465	1-216-845-91	RES, CHIP 100K	(1608)	R694	1-216-835-91 RES, CHIP 15K	(1608)	RB102	1-234-496-21 ARRAY, RESISTOR 39		RB511	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
R466	1-216-821-91	RES, CHIP 1.0K	(1608)	R696	1-216-846-91 RES, CHIP 120K	(1608)	RB103	1-234-496-21 ARRAY, RESISTOR 39		RB517	1-233-575-21 RES, CHIP NETWORK 22		
R467	1-216-833-91	RES, CHIP 10K	(1608)				RB104	1-234-496-21 ARRAY, RESISTOR 39		RB518	1-233-575-21 RES, CHIP NETWORK 22		
				R698	1-216-835-91 RES, CHIP 15K	(1608)	RB105	1-234-496-21 ARRAY, RESISTOR 39					
R469	1-216-833-91	RES, CHIP 10K	(1608)	R699	1-216-833-91 RES, CHIP 10K	(1608)	RB106	1-234-496-21 ARRAY, RESISTOR 39		RB519	1-233-575-21 RES, CHIP NETWORK 22		
R470	1-216-845-91	RES, CHIP 100K	(1608)	R700	1-216-864-91 CONDUCTOR, CHIP	(1608)	RB107	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB520	1-233-575-21 RES, CHIP NETWORK 22		
R472	1-218-871-91	RES, CHIP 10K	(1608)	R801	1-216-864-91 CONDUCTOR, CHIP	(1608)	RB108	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB521	1-233-575-21 RES, CHIP NETWORK 22		
R473	1-218-863-91	RES, CHIP 4.7K	(1608)	R802	1-216-864-91 CONDUCTOR, CHIP	(1608)	RB109	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB522	1-233-575-21 RES, CHIP NETWORK 22		
R474	1-216-853-91	RES, CHIP 470K	(1608)				RB110	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB523	1-233-575-21 RES, CHIP NETWORK 22		
				R803	1-216-864-91 CONDUCTOR, CHIP	(1608)							
R475	1-216-857-91	RES, CHIP 1.0M	(1608)	R804	1-216-864-91 CONDUCTOR, CHIP	(1608)	RB111	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB524	1-233-575-21 RES, CHIP NETWORK 22		
R476	1-216-845-91	RES, CHIP 100K	(1608)	R805	1-216-809-91 RES, CHIP 100	(1608)	RB112	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB525	1-233-575-21 RES, CHIP NETWORK 22		
R479	1-216-864-91	CONDUCTOR, CHIP	(1608)	R806	1-216-833-91 RES, CHIP 10K	(1608)	RB113	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB526	1-233-575-21 RES, CHIP NETWORK 22		
R503	1-216-803-91	RES, CHIP 33	(1608)	R807	1-216-809-91 RES, CHIP 100	(1608)	RB114	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB527	1-233-575-21 RES, CHIP NETWORK 22		
R504	1-216-803-91	RES, CHIP 33	(1608)				RB116	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB528	1-233-575-21 RES, CHIP NETWORK 22		
				R808	1-216-833-91 RES, CHIP 10K	(1608)							
R505	1-216-803-91	RES, CHIP 33	(1608)	R813	1-216-158-91 RES, CHIP 22	(3216)	RB117	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB529	1-233-575-21 RES, CHIP NETWORK 22		
R506	1-216-809-91	RES, CHIP 100	(1608)	R814	1-216-158-91 RES, CHIP 22	(3216)	RB118	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB530	1-233-575-21 RES, CHIP NETWORK 22		
R509	1-216-821-91	RES, CHIP 1.0K	(1608)	R815	1-216-797-91 RES, CHIP 10	(1608)	RB119	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB531	1-233-575-21 RES, CHIP NETWORK 22		
R513	1-216-805-91	RES, CHIP 47	(1608)	R816	1-216-158-91 RES, CHIP 22	(3216)	RB120	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB532	1-233-575-21 RES, CHIP NETWORK 22		
R516	1-216-809-91	RES, CHIP 100	(1608)				RB121	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB602	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
				R817	1-216-158-91 RES, CHIP 22	(3216)							
R517	1-216-809-91	RES, CHIP 100	(1608)	R818	1-216-797-91 RES, CHIP 10	(1608)	RB122	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB603	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R522	1-216-833-91	RES, CHIP 10K	(1608)	R819	1-218-889-91 RES, CHIP 56K	(1608)	RB123	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB606	1-233-412-21 RES, CHIP NETWORK 1.0K	(3216)	
R527	1-216-821-91	RES, CHIP 1.0K	(1608)	R820	1-218-881-91 RES, CHIP 27K	(1608)	RB124	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB607	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R527	1-216-821-91	RES, CHIP 1.0K	(1608)	R821	1-218-881-91 RES, CHIP 27K	(1608)	RB125	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB609	1-233-423-21 RES, CHIP NETWORK 47	(3216)	
R531	1-216-809-91	RES, CHIP 100	(1608)				RB126	1-233-423-21 RES, CHIP NETWORK 47	(3216)	RB611	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
				R822	1-218-881-91 RES, CHIP 27K	(1608)				RB803	1-233-415-21 RES, CHIP NETWORK 10K	(3216)	
R574	1-216-812-91	RES, CHIP 180	(1608)	R823	1-218-890-91 RES, CHIP 62K	(1608)	RB130	1-233-423-21 RES, CHIP NETWORK 47	(3216)				
R575	1-216-850-91	RES, CHIP 270K	(1608)	R826	1-218-871-91 RES, CHIP 10K	(1608)	RB131	1-233-423-21 RES, CHIP NETWORK 47	(3216)				
R576	1-216-833-91	RES, CHIP 10K	(1608)	R827	1-218-871-91 RES, CHIP 10K	(1608)	RB132	1-233-423-21 RES, CHIP NETWORK 47	(3216)				
R577	1-216-818-91	RES, CHIP 560											

Ref.	Part No.	Description
	A-6712-923-A	MOUNTED CIRCUIT BOARD, GB-003 ***** PLACE CODE #25BG
		<BATTERY>
BT101	1-756-076-21	HOLDER, LITHIUM BATTERY
		<CONNECTOR>
CN101	1-815-648-21	PIN, CONNECTOR (PC BOARD)

	A-6712-922-A	MOUNTED CIRCUIT BOARD, SW-358 ***** PLACE CODE #25BG
		<CONNECTOR>
CN751	1-785-470-21	CONNECTOR, FPC(LIF(NON-ZIF))7P
		<DIODE>
D751	8-719-078-90	DIODE CL-165HR/G1-D-T
D752	8-719-080-04	DIODE CL-190UB-X-T
		<TRANSISTOR>
Q751	8-729-013-97	TRANSISTOR RN1304-TE85L
		<RESISTOR>
R751	1-216-833-91	RES, CHIP 10K (1608)
R752	1-216-835-91	RES, CHIP 15K (1608)
R753	1-216-993-91	RES, CHIP 2.4K (1608)
		<SWITCH>
S751	1-771-917-21	SWITCH, TACTILE
S752	1-771-917-21	SWITCH, TACTILE

Ref.	Part No.	Description
		SUPPLIED ACCESSORIES PLACE CODE #23 *****
	A-6785-242-A	ACCESSORY & PACKING GROUP
△ AC	1-555-074-51	CORD, POWER for SCPH-30002
△ AC	1-751-115-21	CORD, POWER for SCPH-30003
△ AC	1-575-131-82	CORD, POWER for SCPH-30004
CONV	1-573-291-12	CONNECTOR, CONVERSION for SCPH-30003/-30004
AV	1-792-028-11	CORD, CONNECTION
CONT	1-792-238-72	DS2 ANALOG CONTROLLER
SH	3-060-494-01	SHEET, PROTECTION
CU	3-064-714-01	CUSHION
PA	3-065-172-01	PAD, TOGETHER PACKING for SCPH-30003/-30004
CA	3-066-440-12	INDIVIDUAL CARTON for SCPH-30002
CA	3-066-440-02	INDIVIDUAL CARTON for SCPH-30003
CA	3-066-446-02	INDIVIDUAL CARTON for SCPH-30004
MC	3-066-441-21	MASTER CARTON, 3 SETS
	A-6785-208-A	ACCESSORY & PACKING GROUP
		MANUAL BLOCK ASSY PLACE CODE #23 *****
	A-6785-243-A	MANUAL BLOCK ASSY, INSTRUCTION for SCPH-30002
	A-6785-245-A	MANUAL BLOCK ASSY, INSTRUCTION for SCPH-30003
	A-6785-241-A	MANUAL BLOCK ASSY, INSTRUCTION for SCPH-30004
RE	3-066-158-02	CARD (A), OWNER REGISTRATION
DISC	3-066-725-02	DISK, DEMONSTRATION
IN	3-068-128-11	INSTRUCTION for SCPH-30002
IN	3-068-129-12	INSTRUCTION for SCPH-30003
IN	3-068-130-13	INSTRUCTION for SCPH-30004
IM	3-068-537-21	MANUAL, INSTRUCTION for SCPH-30002
IM	3-068-537-31	MANUAL, INSTRUCTION for SCPH-30003
IM	3-068-537-41	MANUAL, INSTRUCTION for SCPH-30004
SE	3-987-375-02	SEAL, SEAL

Ref.	Part No.	Description
------	----------	-------------

Ref.	Part No.	Description
------	----------	-------------

SECTION 6
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS
for SCPH-30003D'/30004D'

THIS NOTE IS COMMON FOR PRINTED WIRING
BOARDS AND SCHEMATIC DIAGRAMS.

Note on Printed Wiring Boards :

- Through hole is omitted.
-  : Pattern on the side which is seen.

Note on Schematic Diagram :


- Use caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor,
because it is damaged by the heat.
- All capacitors are in μF unless otherwise noted. pF : $\mu\mu\text{F}$ 50 WV
or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4 W (Chip resistors : 1/10W) unless
otherwise specified.
- Chip resistors are 1/8 W or 1/10 W unless otherwise noted.
 $\text{k}\Omega$: 1000Ω , $\text{M}\Omega$: $1000\text{ k}\Omega$.


Note : The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.	Note : Les composants identifiés par une marque  sont critiques pour la securite. Ne les remplacer que par une piece portant le nubero specifie.
--	---


Note on DC Power line :

Unit of voltage is V (volt)

- | | |
|---|---|
| • +12V :  | • +3.3V :  |
| • +8.0V :  | • +2.5V :  |
| • +5.0V :  | • +1.8V :  |
| • +3.5V :  | • +1.7V :  |
| • +3.4V :  | • +1.5V :  |
-
- | | |
|---|--|
| • IN :  | • Main Signal Line :  |
| • OUT :  | |








GH-012 (3/7)

Reproduction Prohibited



IC518 : for GH012-64MM & GH012-64MR

IC518

TC7WB125FK (TE85R)

C526, C543, R527 :
for GH012-64MM & GH012-64MR

IC503, IC506 :
for GH012-32MM & GH012-32MR

IC503

BOOT ROM

IC506

DVD ROM

IC502

SDMV18165CTM6S
DRAM

SCPH-30002D/30003D/30004D

IC504

CXD2942AR
:for SCPH-30003D/30004D' GH-012-32MR
CXD2942BR
:for SCPH-30003D/30004D' GH-012-64MR

IC505

BOOT + DVD ROM
for GH012-64MM & GH012-64MR

C505, C512, R510, R511 :
for GH012-32MM & GH012-32MR

IC501


CXD9611AR
HDD CONTROLLER

IC517

CS4335-KS
AUDIO DUC

GH-012 (5/7)


Reproduction Prohibited






— 170 —

Reproduction Prohibited




GH-012


B side




GB-004
A side




GB-004
A side




GB-004
B side



SW-363
A side



SW-363
B side



SW-363

SECTION 7

ELECTRICAL PARTS LIST

for SCPH-30003D'/30004D' GH012 MOUNT

NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
METAL : Metal-film resistor.
F : nonflammable
Unit is Ω.
- SEMICONDUCTORS
In each case, u : μ, for example :
uA . . . : μA . . . uPA . . . : μPA . . .
uPB . . . : μPB . . . uPC . . . : μPC . . . uPD . . . : μPD . . .
- CAPACITORS
uF : μF
• COILS
uH : μH

The components identified by mark $\triangle$ or dotted line with mark. $\triangle$ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref.	Part No.	Description
A-6712-985-A	GH-012 MOUNT (32M R)	
	for SCPH-30003D' & 30004D' GH-012-32MR	
A-6712-986-A	GH-012 MOUNT (64M R)	
	for SCPH-30003D' & 30004D' GH-012-64MR	

Dissimilarity Parts

for SCPH-30003D' & 30004D' GH-012-32MR			*****		
C505	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)		
C512	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)		
IC503	6-800-197-01	IC MR27V3202F-A7TPZ			
IC504	8-752-408-53	IC CXD2942AR			
IC506	6-800-198-01	IC MR27V1602E-74TPZ			
R510	1-216-864-91	CONDUCTOR, CHIP	(1608)		
R511	1-216-864-91	CONDUCTOR, CHIP	(1608)		
for SCPH-30003D' & 30004D' GH-012-64MR			*****		
C526	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F	(1608)		
C543	1-113-619-91	CAP, CERAMIC 470000PF F	(1608)		
IC504	8-752-410-55	IC CXD2942BR			
IC505	6-800-196-01	IC TC5364200FT-PA06			
IC518	8-759-680-49	IC TC7WB125FK(TE85R)			
R527	1-216-821-91	RES, CHIP 1.0K	(1608)		
for IC801 : SP3727ACA0PMR(8-7529-685-15)			*****		
C632	1-107-826-91	CAP, CHIP CERAMIC 100000PF			
C689	1-162-968-91	CAP, CHIP CERAMIC 100000PF			
IC606	8-759-712-38	IC HD74HC1G66CME			
IC606	8-759-712-63	IC MC74VHC1G66DFT1			
IC801	8-7529-685-15	IC SP3727ACA0PMR			
R640	1-216-837-91	RES, CHIP 22K (1608)			
R643	1-216-850-91	RES, CHIP 270K (1608)			
for IC801:SP3727AFA0PMR(6-700-585-01)			*****		
IC801	6-700-585-01	IC SP3727AFA0PMR			
R640	1-216-864-91	CONDUCTOR, CHIP (1608)			

Common Parts

<CAPACITOR>		
C101	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C102	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C103	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C104	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C105	1-107-826-91	CAP, CHIP CERAMIC 100000PF B

Ref.	Part No.	Description
C106	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C107	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C108	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C109	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C110	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C111	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C112	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C113	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C114	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C115	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C116	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C117	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C118	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C119	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C120	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C121	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C122	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C123	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C124	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C125	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C126	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C127	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C128	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C129	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C131	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C132	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C134	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C135	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C136	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C137	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C138	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C139	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C140	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C141	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF
C142	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C143	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C144	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C145	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C146	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C147	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C148	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C149	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C150	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C151	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C152	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C153	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C154	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C155	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C156	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C157	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C158	1-162-970-91	CAP, CERAMIC 10000PF B (1608)

Ref.	Part No.	Description
C159	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C160	1-162-925-91	CAP, CERAMIC 68PF CH (1608)
C161	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C162	1-162-925-91	CAP, CERAMIC 68PF CH (1608)
C163	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C164	1-128-964-91	CAP, CHIP TANTALUM ELECT 100MF
C168	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C169	1-164-874-81	CAP, CHIP CERAMIC 100PF CH (1005)
C170	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C175	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C176	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C201	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C203	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C204	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C205	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C206	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C208	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C209	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C210	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C211	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C212	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C213	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C214	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C215	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C216	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C217	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C218	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C219	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C220	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C221	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C222	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C223	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C224	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C225	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C226	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C227	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C228	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C229	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C230	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C231	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C232	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C233	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C234	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C235	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C236	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C237	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C238	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C239	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C240	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C241	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C242	1-128-707-22	CAP, TANTALUM ELECT (SMD)220
C243	1-128-707-22	CAP, TANTALUM ELECT (SMD)220
C244	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF
C245	1-128-707-22	CAP, TANTALUM ELECT (SMD)220
C246	1-135-609-91	CAP, CHIP TANTALUM ELECT 220MF
C247	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C248	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C249	1-115-156-91	CAP, CERAMIC 1000000PF F (1608)
C250	1-127-760-91	CAP, CERAMIC 4.7MF (2012)
C252	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C254	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C255	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C256	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C257	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C261	1-128-004-21	CAP, ELECT (CHIP) 10MF
C262	1-128-004-21	CAP, ELECT (CHIP) 10MF

Ref.	Part No.	Description
C263	1-128-004-21	CAP, ELECT (CHIP) 10MF
C265	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)
C266	1-128-004-21	CAP, ELECT (CHIP) 10MF
C267	1-126-210-21	CAP, ELECT 220MF
C268	1-126-210-21	CAP, ELECT 220MF
C269	1-164-160-91	CAP, CERAMIC 20PF CH (1608)
C270	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)
C271	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C272	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C275	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C276	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C277	1-162-965-91	CAP, CERAMIC 1500PF B (1608)
C278	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C279	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C282	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C285	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C286	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C287	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C288	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C289	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C290	1-113-619-91	CAP, CERAMIC 470000PF F (1608)
C291	1-164-866-81	CAP, CHIP CERAMIC 47PF CH (1005)
C292	1-107-725-91	CAP, CERAMIC 100000PF B (2012)
C293	1-137-765-21	CAP, ELECT 47MF
C296	1-126-210-21	CAP, ELECT 220MF
C297	1-126-210-21	CAP, ELECT 220MF
C298	1-126-210-21	CAP, ELECT 220MF
C301	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C302	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C303	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C304	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C305	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C306	1-164-387-91	CAP, CERAMIC 240PF CH (1608)
C307	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C308	1-165-112-91	CAP, CERAMIC 330000PF F (1608)
C309	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C310	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C311	1-162-916-91	CAP, CERAMIC 12PF CH (1608)
C312	1-162-917-91	CAP, CERAMIC 15PF CH (1608)
C313	1-162-910-91	CAP, CERAMIC 5.0PF CH (1608)
C314	1-162-910-91	CAP, CERAMIC 5.0PF CH (1608)
C315	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C316	1-165-112-91	CAP, CERAMIC 330000PF F (1608)
C317	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C318	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C319	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C320	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C321	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C322	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C323	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C324	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C325	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C326	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C327	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C328	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C329	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C330	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C331	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C332	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C333	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C334	1-162-970-91	CAP,

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
C340	1-125-764-61	CAP, CHIP CERAMIC 100PF CH	C456	1-127-760-91	CAP, CERAMIC 4.7MF (2012)	C541	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C709	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C341	1-125-764-61	CAP, CHIP CERAMIC 100PF CH				C542	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C710	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C342	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C457	1-127-760-91	CAP, CERAMIC 4.7MF (2012)	C544	1-137-765-21	CAP, ELECT 47MF	C712	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C343	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C458	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C545	1-137-765-21	CAP, ELECT 47MF	C714	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C344	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C460	1-164-174-91	CAP, CERAMIC 8200PF B (1608)	C601	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)			
C345	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C461	1-164-174-91	CAP, CERAMIC 8200PF B (1608)				C715	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C355	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C462	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)	C603	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C716	1-131-999-21	CAP, SOLID ELECT 150MF
C356	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)				C605	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C717	1-135-346-21	CAP, SOLID ELECT 39MF
C363	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C465	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C606	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C718	1-135-346-21	CAP, SOLID ELECT 39MF
C364	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C466	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C607	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)	C722	1-164-937-81	CAP, CHIP CERAMIC 1000PF B (1005)
C365	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C467	1-126-209-21	CAP, ELECT 100MF	C609	1-107-826-91	CAP, CHIP CERAMIC 100000PF B			
C366	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C468	1-126-209-21	CAP, ELECT 100MF				C723	1-137-766-21	CAP, ELECT 68MF
			C469	1-162-977-91	CAP, CERAMIC 1800PF B (1608)	C623	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C724	1-137-765-21	CAP, ELECT 47MF
C367	1-107-826-91	CAP, CHIP CERAMIC 100000PF B				C624	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C725	1-124-779-21	CAP, ELECT 10MF
C368	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C470	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C625	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C726	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C369	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C471	1-164-379-91	CAP, CERAMIC 43PF CH (1608)	C629	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C727	1-164-937-81	CAP, CHIP CERAMIC 1000PF B (1005)
C370	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C472	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C630	1-164-173-91	CAP, CERAMIC 3900PF B (1608)			
C371	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C473	1-162-970-91	CAP, CERAMIC 10000PF B (1608)				C730	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF
			C474	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C631	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)	C791	1-164-245-91	CAP, CERAMIC 15000PF B (1608)
C372	1-165-492-21	CAP, ELECT 100MF				C633	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C792	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF
C373	1-165-492-21	CAP, ELECT 100MF	C475	1-164-730-91	CAP, CERAMIC 1200PF B (1608)	C634	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C793	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)
C401	1-125-777-81	CAP, CHIP CERAMIC 0.1MF B (1005)	C476	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)	C635	1-162-968-91	CAP, CHIP CERAMIC 4700PF B (1608)	C794	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)
C402	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)	C477	1-127-760-91	CAP, CERAMIC 4.7MF (2012)	C636	1-107-826-91	CAP, CHIP CERAMIC 100000PF B			
C403	1-164-937-81	CAP, CHIP CERAMIC 1000PF B (1005)	C479	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)				C795	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)
			C480	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)	C637	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C797	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C404	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)				C638	1-107-726-91	CAP, CHIP CERAMIC 10000PF B (1608)	C798	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C405	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C482	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C639	1-164-217-91	CAP, CERAMIC 150PF CH (1608)	C801	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)
C406	1-135-593-21	CAP, ELECT 150MF	C483	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C640	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF	C802	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)
C407	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C485	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C642	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)			
C408	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C486	1-137-765-21	CAP, ELECT 47MF				C803	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
			C487	1-131-999-21	CAP, SOLID ELECT 150MF	C643	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C804	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C409	1-162-969-91	CAP, CERAMIC 6800PF B (1608)				C644	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C805	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C411	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)	C488	1-115-566-91	CAP, CERAMIC 4.7MF B	C645	1-165-176-91	CAP, CERAMIC 47000PF B (1608)	C806	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C414	1-162-965-91	CAP, CERAMIC 1500PF B (1608)	C489	1-131-999-21	CAP, SOLID ELECT 150MF	C646	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C807	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
C415	1-165-176-91	CAP, CERAMIC 47000PF B (1608)	C490	1-126-209-21	CAP, ELECT 100MF	C647	1-117-863-91	CAP, CHIP CERAMIC 0.47MF B (1608)			
C416	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C492	1-107-826-91	CAP, CHIP CERAMIC 100000PF B				C808	1-162-927-91	CAP, CERAMIC 100PF CH (1608)
			C493	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C648	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C809	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C417	1-164-379-91	CAP, CERAMIC 43PF CH (1608)				C649	1-107-726-91	CAP, CHIP CERAMIC 10000PF B (1608)	C810	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF
C418	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C494	1-107-725-91	CAP, CERAMIC 100000PF B (2012)	C650	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C811	1-135-900-21	CAP, TANTALUM ELECT 22MF
C419	1-162-970-91	CAP, CERAMIC 10000PF B (1608)	C495	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C651	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C812	1-164-730-91	CAP, CERAMIC 1200PF B (1608)
C420	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C496	1-107-682-91	CAP, CERAMIC 1000000PF B (3216)	C652	1-107-826-91	CAP, CHIP CERAMIC 100000PF B			
C421	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF	C498	1-127-760-91	CAP, CERAMIC 4.7MF (2012)				C819	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
			C499	1-164-505-91	CAP, CHIP CERAMIC 2.2MF F (2012)	C653	1-162-966-91	CAP, CERAMIC 2200PF B (1608)	C821	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF
C422	1-107-826-91	CAP, CHIP CERAMIC 100000PF B				C654	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C824	1-135-900-21	CAP, TANTALUM ELECT 22MF
C423	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C501	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)	C655	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF	C825	1-164-730-91	CAP, CERAMIC 1200PF B (1608)
C424	1-127-820-91	CAP, SQUARE TYPE CHIP 4.7MF	C502	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C656	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C826	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C425	1-124-779-21	CAP, ELECT 10MF	C503	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)	C657	1-164-230-91	CAP, CERAMIC 220PF CH (1608)			
C426	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C504	1-164-346-91	CAP, CHIP CERAMIC 1MF F (2012)				C827	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
			C507	1-163-009-91	CAP, CHIP CERAMIC 1000PF B (2012)	C658	1-164-230-91	CAP, CERAMIC 220PF CH (1608)	C828	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C427	1-117-681-21	CAP, ELECT 100MF				C660	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C829	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C430	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C508	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C661	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C830	1-162-966-91	CAP, CERAMIC 2200PF B (1608)
C431	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C509	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C662	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C831	1-162-975-91	CAP, CERAMIC 24PF CH (1608)
C432	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)	C510	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C664	1-135-259-91	CAP, CHIP TANTALUM ELECT 10MF			
C433	1-115-339-91	CAP, CERAMIC 0.1MF B (2012)	C513	1-113-619-91	CAP, CERAMIC 470000PF F (1608)				C832	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)
			C514	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C665	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C834	1-163-038-91	CAP, CERAMIC 100000PF F (2012)
C434	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)				C666	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C835	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C435	1-115-566-91	CAP, CERAMIC 4.7MF B	C516	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C667	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C836	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C436	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)	C517	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C668	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C837	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C437	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C518	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C671	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)			
C438	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C521	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)				C839	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
			C522	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C672	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C840	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C439	1-135-593-21	CAP, ELECT 150MF				C673	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C841	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C440	1-135-592-21	CAP, ELECT 100MF	C523	1-107-726-91	CAP, CHIP CERAMIC 10000PF B (1608)	C674	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)	C842	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C441	1-135-593-21	CAP, ELECT 150MF	C524	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C675	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)	C843	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C443	1-135-592-21	CAP, ELECT 100MF	C525	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C676	1-164-360-91	CAP, CERAMIC 0.1MF F (1608)			
C444	1-107-826-91	CAP, CHIP CERAMIC 100000PF B	C527	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)				C844	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
			C528	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)	C685	1-117-863-91	CAP, CHIP CERAMIC 0.47MF B (1608)	C845	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
C445	1-117-720-91	CAP, CERAMIC 4.7MF F (2012)				C688	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C846	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C446	1-135-592-21	CAP, ELECT 100MF	C529	1-128-008-21	CAP, ELECT (CHIP) 3.3MF	C693	1-162-912-91	CAP, CERAMIC 7.0PF CH (1608)	C848	1-107-823-91	CAP, CERAMIC 470000PF B (2012)
C447	1-107-682-91	CAP, CERAMIC 1000000PF B (3216)	C530	1-128-008-21	CAP, ELECT (CHIP) 3.3MF	C701	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C850	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C448	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)	C533	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C702	1-162-927-91	CAP, CERAMIC 100PF CH (1608)			
C449	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)	C534	1-113-619-91	CAP, CERAMIC 470000PF F (1608)				C851	1-162-970-91	CAP, CERAMIC 10000PF B (1608)
			C535	1-113-619-91	CAP, CERAMIC 470000PF F (1608)	C703	1-162-927-91	CAP, CERAMIC 100PF CH (1608)	C853	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C450	1-107-826-91	CAP, CHIP CERAMIC 100000PF B									

Ref.	Part No.	Description
C862	1-164-739-91	CAP, CERAMIC 560PF CH (1608)
C863	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C866	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C868	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C869	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C870	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C871	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C872	1-115-467-91	CAP, CHIP CERAMIC 0.22MF B (1608)
C873	1-164-392-91	CAP, CERAMIC 390PF CH (1608)
C874	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C875	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C876	1-125-838-91	CAP, CHIP CERAMIC 2.2MF B (2012)
C877	1-164-173-91	CAP, CERAMIC 3900PF B (1608)
C879	1-164-739-91	CAP, CERAMIC 560PF CH (1608)
C880	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C882	1-127-692-91	CAP, CHIP CERAMIC 10MF B (3225)
C883	1-163-038-91	CAP, CERAMIC 100000PF F (2012)
C888	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C889	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C890	1-104-851-91	CAP, CHIP TANTALUM ELECT 10MF
C891	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C895	1-162-964-91	CAP, CHIP CERAMIC 1000PF B (1608)
C897	1-164-677-91	CAP, CERAMIC 33000PF B (1608)
C898	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C899	1-164-156-91	CAP, CHIP CERAMIC 0.1MF F (1608)
C901	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C902	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C903	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C904	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C905	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C906	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C907	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C908	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C909	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C910	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C911	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C912	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C913	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C914	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C915	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C916	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C917	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C918	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C919	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C920	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C921	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C922	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C923	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C924	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C925	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C926	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C927	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C928	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C929	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C930	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C931	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C932	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C933	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C934	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C935	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C936	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C937	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C938	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C939	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C940	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C941	1-107-826-91	CAP, CHIP CERAMIC 100000PF B

Ref.	Part No.	Description
C942	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C943	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C944	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C945	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C946	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C947	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C948	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C949	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C950	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C951	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C952	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C953	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C954	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C955	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C956	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C957	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C958	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C959	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C960	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C961	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C962	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C963	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C965	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C966	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C967	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C968	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C980	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C981	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C982	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C983	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C984	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C985	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C986	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C987	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C988	1-125-837-91	CAP, CHIP CERAMIC 1MF B (1608)
C989	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
C990	1-107-826-91	CAP, CHIP CERAMIC 100000PF B
<CONNECTOR>		
CN201	1-815-631-11	CONNECTOR, SQUARE TYPE 12P
CN302	1-794-206-21	CONNECTOR, FFC/FPC (ZIF) 36P
CN303	1-694-822-11	TERMINAL BOARD (ILINK/USB)
CN401	1-815-630-11	PIN, CONNECTOR 4P
CN402	1-815-648-21	PIN, CONNECTOR (PC BOARD) 2P
CN403	1-784-650-21	CONNECTOR 2P
CN406	1-815-653-21	CONNECTOR, FFC/FPC (ZIF) 7P
CN501	1-476-736-11	TRANSMITTER UNIT, LIGHT
CN504	1-815-632-11	CONNECTOR BOARD TO BOARD 110P
CN801	1-794-237-21	CONNECTOR, FFC/FPC 30P
CN802	1-770-619-41	PIN, CONNECTOR 2P
CN803	1-779-206-21	CONNECTOR, FFC/LIF(NON-ZIF)4P
CN804	1-794-194-21	CONNECTOR, FFC/FPC 13P
CN805	1-770-619-21	PIN, CONNECTOR 2P
CN806	1-770-619-81	PIN, CONNECTOR 2P
<NETWORK>		
CP201	1-234-605-21	NETWORK, RC
<DIODE>		
D201	8-719-065-78	DIODE MAZF12000LS0
D202	8-719-064-61	DIODE 01BZA8.2(TE85L)
D203	8-719-064-61	DIODE 01BZA8.2(TE85L)
D204	8-719-064-61	DIODE 01BZA8.2(TE85L)
D205	8-719-064-61	DIODE 01BZA8.2(TE85L)
D206	8-719-064-61	DIODE 01BZA8.2(TE85L)
D208	8-719-064-61	DIODE 01BZA8.2(TE85L)

Ref.	Part No.	Description
D209	8-719-064-61	DIODE 01BZA8.2(TE85L)
D210	8-719-064-61	DIODE 01BZA8.2(TE85L)
D301	8-719-071-87	DIODE MA785-(TX),SO
D402	8-719-074-34	DIODE RB495D-T146
D403	8-719-074-34	DIODE RB495D-T146
D404	8-719-033-15	DIODE HN2D02FU-TE85R
D405	8-719-078-04	DIODE EC31QS03L-TE12L
D407	8-719-074-34	DIODE RB495D-T146
D408	8-719-074-34	DIODE RB495D-T146
D500	8-719-941-21	DIODE DAP202UT106
D501	8-719-082-76	DIODE CL-201TLY-C-TU
D801	8-719-065-68	DIODE MAZF04700LS0
D802	8-719-065-68	DIODE MAZF04700LS0
<FUSE>		
△ F001	1-576-434-21	FUSE, CHIP
△ F003	1-576-434-21	FUSE, CHIP
<FERRITE BEAD>		
FB102	1-469-667-21	FERRITE, EMI (SMD)
FB103	1-469-667-21	FERRITE, EMI (SMD)
FB201	1-414-813-21	FERRITE, EMI (SMD)
FB202	1-500-113-22	BEAD, FERRITE (CHIP)
FB203	1-500-113-22	BEAD, FERRITE (CHIP)
FB204	1-500-113-22	BEAD, FERRITE (CHIP)
FB205	1-500-113-22	BEAD, FERRITE (CHIP)
FB206	1-500-113-22	BEAD, FERRITE (CHIP)
FB207	1-469-667-21	FERRITE, EMI (SMD)
FB208	1-469-667-21	FERRITE, EMI (SMD)
FB303	1-414-555-21	FERRITE, EMI (SMD)
FB304	1-414-555-21	FERRITE, EMI (SMD)
FB305	1-414-555-21	FERRITE, EMI (SMD)
FB306	1-414-555-21	FERRITE, EMI (SMD)
FB307	1-414-555-21	FERRITE, EMI (SMD)
FB308	1-414-555-21	FERRITE, EMI (SMD)
FB309	1-414-555-21	FERRITE, EMI (SMD)
FB310	1-414-555-21	FERRITE, EMI (SMD)
FB311	1-414-555-21	FERRITE, EMI (SMD)
FB312	1-414-555-21	FERRITE, EMI (SMD)
FB313	1-469-324-21	FERRITE, EMI (SMD)
FB314	1-469-324-21	FERRITE, EMI (SMD)
FB315	1-469-324-21	FERRITE, EMI (SMD)
FB316	1-469-324-21	FERRITE, EMI (SMD)
FB317	1-469-110-21	FERRITE, EMI (SMD)
FB318	1-469-110-21	FERRITE, EMI (SMD)
FB319	1-469-110-21	FERRITE, EMI (SMD)
FB320	1-469-110-21	FERRITE, EMI (SMD)
FB321	1-469-110-21	FERRITE, EMI (SMD)
FB322	1-469-110-21	FERRITE, EMI (SMD)
FB323	1-469-110-21	FERRITE, EMI (SMD)
FB324	1-469-110-21	FERRITE, EMI (SMD)
FB403	1-469-667-21	FERRITE, EMI (SMD)
FB404	1-469-667-21	FERRITE, EMI (SMD)
FB405	1-469-667-21	FERRITE, EMI (SMD)
FB406	1-469-667-21	FERRITE, EMI (SMD)
FB407	1-469-667-21	FERRITE, EMI (SMD)
FB408	1-469-667-21	FERRITE, EMI (SMD)
FB409	1-469-667-21	FERRITE, EMI (SMD)
FB801	1-469-562-21	FERRITE, EMI (SMD)
FB802	1-469-562-21	FERRITE, EMI (SMD)
<FILTER>		
FL201	1-469-991-21	EMI FILTER (SMD)
FL202	1-469-991-21	EMI FILTER (SMD)
FL203	1-469-991-21	EMI FILTER (SMD)
FL301	1-234-601-21	NETWORK, RC (USB)

Ref.	Part No.	Description	
FL302	1-234-601-21	NETWORK, RC (USB)	(3216)
		<IC>	
IC101	8-759-831-20	IC CY2212ZC-2T	
IC102	8-759-837-33	IC K4R271669A-SCK8T00	
IC103	8-759-837-33	IC K4R271669A-SCK8T00	
IC104	8-759-699-09	IC CXD9615GB	
IC105	8-759-689-90	IC LM74CIMX-3	
IC201	8-759-831-20	IC CY2212ZC-2T	
IC202	8-752-404-01	IC CXD2934GB-T7	for CEX-DA10002B/C model only
IC205	6-700-230-01	IC SC44728BPBEB	for CEX-DA10002B/C model only
IC206	8-752-093-56	IC CXA3525R-T4	
IC206	8-752-099-53	IC CXA3525BR-T4	
IC207	8-759-391-69	IC MC78M05CDTRK	
IC207	8-759-691-00	IC JCP78M05CDTRK	
IC207	8-759-697-61	IC L78M05CDT-TR(P)	
IC209	8-759-697-60	IC MM3071CFBE	
IC303	8-759-699-11	IC CXD9619GB	
IC305	6-700-549-01	IC K4Q153212MJC60T	
IC305	6-700-119-01	IC T5NB8(YEL)	
IC306	8-759-688-07	IC MM3051NUL	
IC306	8-759-697-24	IC S-817A12ANB-CUB-T2	
IC401	8-759-661-25	IC S-80769SN-J0-T1	
IC402	8-759-837-34	IC TMP87C807U-2A69(EL)	
IC403	6-700-234-01	IC BD3992F-E2	
IC403	6-700-234-01	IC BD3992F-E2	
IC404	8-759-689-89	IC SN104809DBTR	
IC405	8-759-560-17	IC RS5C348A-E2	
IC406	8-759-698-67	IC BR2880F-E2	
IC407	8-759-712-66	IC PQ018PZ012P	
IC408	8-759-712-65	IC PQ070XZ012P	
IC409	8-759-689-89	IC SN104809DBTR	
IC410	8-749-018-42	IC SI-3026LSA-TL	
IC411	8-759-688-06	IC MM3031JULE	
IC413	6-700-233-01	IC MM1573ZNL	
IC413	8-759-598-12	IC LP2985IM5X-3.5	
IC414	8-759-069-41	IC TA7808F(TE16L)	
IC414	8-759-473-16	IC BA17808FP-E2	
IC414	8-759-697-62	IC NJM7808DL1A(TE1)	
IC415	8-759-581-11	IC NJM2125F(TE2)	
IC501	6-700-231-01	IC CXD9611AR	
IC501	8-759-699-10	IC CXD9611R	
IC502	8-759-712-79	IC K4E151612D-TL50T00	
IC502	8-759-712-80	IC MT4LC1M16E5TG-5TR	
IC502	8-759-712-81	IC GM71V18163CT-5	
IC502	8-759-712-82	IC SDMV18165CTM6S	
IC504	8-752-408-53	IC CXD2942AR	
IC517	8-759-667-10	IC CS4335-KS	
IC603	8-759-370-11	IC NJM2100V-TE2	
IC604	8-752-921-99	IC CXP102064-202R-T6	
IC604	8-752-921-99	IC CXP102064-202R-T6	
IC604	8-752-924-75	IC CXP102064-203R-T6	
IC605	8-752-414-53	IC CXD1869AQ-2	
IC605	8-752-413-11	IC CXD1869BQ	
IC802	8-759-697-65	IC BA5815FM-E2	
IC803	8-759-588-60	IC BA6664FM-E2	
IC805	8-759-712-38	IC HD74HC1G66CME	
IC805	8-759-712-63	IC MC74VHC1G66DFT1	
IC806	8-759-337-40	IC NJM2904V(TE2)	
IC807	8-759-391-69	IC MC78M05CDTRK	
IC807	8-759-691-00	IC JCP78M05CDTRK	
IC807	8-759-697-61	IC L78M05CDT-TR(P)	

— 177 —

Ref.	Part No.	Description
R509	1-216-821-91	RES, CHIP 1.0K
R513	1-216-805-91	RES, CHIP 47
R516	1-216-809-91	RES, CHIP 100
R517	1-216-809-91	RES, CHIP 100
R522	1-216-833-91	RES, CHIP 10K
R531	1-216-809-91	RES, CHIP 100
R574	1-216-812-91	RES, CHIP 180
R575	1-216-850-91	RES, CHIP 270K
R576	1-216-833-91	RES, CHIP 10K
R577	1-216-818-91	RES, CHIP 560
R578	1-216-818-91	RES, CHIP 560
R579	1-216-833-91	RES, CHIP 10K
R580	1-216-850-91	RES, CHIP 270K
R604	1-216-845-91	RES, CHIP 100K
R606	1-216-833-91	RES, CHIP 10K
R607	1-216-833-91	RES, CHIP 10K
R613	1-216-833-91	RES, CHIP 10K
R614	1-216-833-91	RES, CHIP 10K
R619	1-216-833-91	RES, CHIP 10K
R620	1-216-833-91	RES, CHIP 10K
R623	1-216-837-91	RES, CHIP 22K
R624	1-216-850-91	RES, CHIP 270K
R625	1-216-864-91	CONDUCTOR, CHIP
R626	1-216-833-91	RES, CHIP 10K
R627	1-216-837-91	RES, CHIP 22K
R630	1-216-837-91	RES, CHIP 22K
R636	1-216-864-91	CONDUCTOR, CHIP
R642	1-216-833-91	RES, CHIP 10K
R644	1-216-837-91	RES, CHIP 22K
R649	1-216-833-91	RES, CHIP 10K
R650	1-216-833-91	RES, CHIP 10K
R651	1-216-835-91	RES, CHIP 15K
R653	1-216-845-91	RES, CHIP 100K
R654	1-216-845-91	RES, CHIP 100K
R657	1-216-839-91	RES, CHIP 33K
R658	1-216-833-91	RES, CHIP 10K
R660	1-216-833-91	RES, CHIP 10K
R661	1-216-833-91	RES, CHIP 10K
R667	1-216-861-91	RES, CHIP 2.2M
R668	1-216-853-91	RES, CHIP 470K
R669	1-216-845-91	RES, CHIP 100K
R670	1-216-833-91	RES, CHIP 10K
R671	1-216-827-91	RES, CHIP 3.3K
R672	1-218-888-91	RES, CHIP 51K
R673	1-216-827-91	RES, CHIP 3.3K
R674	1-216-845-91	RES, CHIP 100K
R675	1-216-839-91	RES, CHIP 33K
R678	1-216-829-91	RES, CHIP 4.7K
R689	1-216-845-91	RES, CHIP 100K
R694	1-216-835-91	RES, CHIP 15K
R696	1-216-846-91	RES, CHIP 120K
R698	1-216-835-91	RES, CHIP 15K
R699	1-216-833-91	RES, CHIP 10K
R700	1-216-864-91	CONDUCTOR, CHIP
R801	1-216-864-91	CONDUCTOR, CHIP
R802	1-216-864-91	CONDUCTOR, CHIP
R803	1-216-864-91	CONDUCTOR, CHIP
R804	1-216-864-91	CONDUCTOR, CHIP
R805	1-216-809-91	RES, CHIP 100
R806	1-216-833-91	RES, CHIP 10K
R807	1-216-809-91	RES, CHIP 100
R808	1-216-833-91	RES, CHIP 10K
R813	1-216-158-91	RES, CHIP 22
R814	1-216-158-91	RES, CHIP 22
R815	1-216-797-91	RES, CHIP 10
R816	1-216-158-91	RES, CHIP 22

Ref.	Part No.	Description
R817	1-216-158-91	RES, CHIP 22
R818	1-216-797-91	RES, CHIP 10
R819	1-218-889-91	RES, CHIP 56K
R820	1-218-881-91	RES, CHIP 27K
R821	1-218-881-91	RES, CHIP 27K
R822	1-218-881-91	RES, CHIP 27K
R823	1-218-890-91	RES, CHIP 62K
R826	1-218-871-91	RES, CHIP 10K
R827	1-218-871-91	RES, CHIP 10K
R828	1-218-881-91	RES, CHIP 27K
R830	1-216-815-91	RES, CHIP 330
R831	1-216-810-91	RES, CHIP 120
R834	1-208-911-81	RES, CHIP 10K
R837	1-208-922-81	RES, CHIP 30K
R838	1-208-922-81	RES, CHIP 30K
R840	1-208-916-81	RES, CHIP 16K
R843	1-208-922-81	RES, CHIP 30K
R846	1-208-922-81	RES, CHIP 30K
R847	1-218-977-81	RES, CHIP 100K
R850	1-208-911-81	RES, CHIP 10K
R851	1-208-916-81	RES, CHIP 16K
R852	1-218-873-91	RES, CHIP 12K
R853	1-216-298-91	RES, CHIP 2.2
R854	1-216-298-91	RES, CHIP 2.2
R855	1-216-298-91	RES, CHIP 2.2
R856	1-216-298-91	RES, CHIP 2.2
R866	1-216-845-91	RES, CHIP 100K
R868	1-216-849-91	RES, CHIP 220K
R870	1-216-849-91	RES, CHIP 220K
R871	1-218-896-91	RES, CHIP 110K
R872	1-216-844-91	RES, CHIP 82K
R873	1-216-839-91	RES, CHIP 33K
R874	1-216-828-91	RES, CHIP 3.9K
R875	1-216-023-91	RES, CHIP 82
R876	1-216-023-91	RES, CHIP 82
R877	1-216-023-91	RES, CHIP 82
R878	1-216-023-91	RES, CHIP 82
R879	1-216-023-91	RES, CHIP 82
R880	1-216-023-91	RES, CHIP 82
R881	1-216-023-91	RES, CHIP 82
R882	1-216-023-91	RES, CHIP 82
R901	1-218-937-81	RES, CHIP 47
R902	1-218-937-81	RES, CHIP 47
R974	1-216-801-91	RES, CHIP 22
R975	1-216-801-91	RES, CHIP 22
R984	1-216-864-91	CONDUCTOR, CHIP
RB101	1-234-496-21	ARRAY, RESISTOR 39
RB102	1-234-496-21	ARRAY, RESISTOR 39
RB103	1-234-496-21	ARRAY, RESISTOR 39
RB104	1-234-496-21	ARRAY, RESISTOR 39
RB105	1-234-496-21	ARRAY, RESISTOR 39
RB106	1-234-496-21	ARRAY, RESISTOR 39
RB107	1-233-575-21	RES, CHIP NETWORK 22
RB108	1-233-575-21	RES, CHIP NETWORK 22
RB109	1-233-575-21	RES, CHIP NETWORK 22
RB110	1-233-575-21	RES, CHIP NETWORK 22
RB111	1-233-575-21	RES, CHIP NETWORK 22
RB112	1-233-575-21	RES, CHIP NETWORK 22
RB113	1-233-575-21	RES, CHIP NETWORK 22
RB114	1-233-575-21	RES, CHIP NETWORK 22
RB115	1-233-575-21	RES, CHIP NETWORK 22
RB116	1-233-575-21	RES, CHIP NETWORK 22
RB117	1-233-575-21	RES, CHIP NETWORK 22
RB118	1-233-575-21	RES, CHIP NETWORK 22
RB119	1-233-575-21	RES, CHIP NETWORK 22
RB120	1-233-575-21	RES, CHIP NETWORK 22

Ref.	Part No.	Description
RB121	1-233-575-21	RES, CHIP NETWORK 22
RB122	1-233-575-21	RES, CHIP NETWORK 22
RB123	1-233-575-21	RES, CHIP NETWORK 22
RB124	1-233-575-21	RES, CHIP NETWORK 22
RB125	1-233-575-21	RES, CHIP NETWORK 22
RB126	1-233-575-21	RES, CHIP NETWORK 22
RB130	1-233-423-21	RES, CHIP NETWORK 47
RB131	1-233-423-21	RES, CHIP NETWORK 47
RB132	1-233-423-21	RES, CHIP NETWORK 47
RB133	1-233-423-21	RES, CHIP NETWORK 47
RB134	1-233-423-21	RES, CHIP NETWORK 47
RB135	1-233-423-21	RES, CHIP NETWORK 47
RB136	1-233-423-21	RES, CHIP NETWORK 47
RB137	1-233-423-21	RES, CHIP NETWORK 47
RB139	1-233-414-21	RES, CHIP NETWORK 4.7K
RB241	1-233-414-21	RES, CHIP NETWORK 4.7K
RB294	1-233-414-21	RES, CHIP NETWORK 4.7K
RB295	1-233-412-21	RES, CHIP NETWORK 1.0K
RB296	1-234-598-21	RES, CHIP NETWORK 75X4
RB297	1-234-599-21	RES, CHIP NETWORK 180X4
RB298	1-234-598-21	RES, CHIP NETWORK 75X4
RB303	1-233-412-21	RES, CHIP NETWORK 1.0K
RB305	1-233-575-21	RES, CHIP NETWORK 22
RB310	1-233-681-91	RES, NETWORK 4.7K
RB311	1-233-679-91	RES, NETWORK 470
RB312	1-233-786-91	RES, NETWORK 220
RB314	1-233-681-91	RES, NETWORK 4.7K
RB317	1-233-423-21	RES, CHIP NETWORK 47
RB318	1-233-423-21	RES, CHIP NETWORK 47
RB319	1-233-423-21	RES, CHIP NETWORK 47
RB320	1-233-423-21	RES, CHIP NETWORK 47
RB321	1-233-423-21	RES, CHIP NETWORK 47
RB322	1-233-412-21	RES, CHIP NETWORK 1.0K
RB323	1-233-412-21	RES, CHIP NETWORK 1.0K
RB324	1-233-412-21	RES, CHIP NETWORK 1.0K
RB325	1-233-412-21	RES, CHIP NETWORK 1.0K
RB326	1-233-412-21	RES, CHIP NETWORK 1.0K
RB327	1-233-415-21	RES, CHIP NETWORK 10K
RB328	1-233-414-21	RES, CHIP NETWORK 4.7K
RB329	1-233-783-91	RES, NETWORK 22
RB402	1-233-803-91	RES, NETWORK 1.5K
RB403	1-233-789-91	RES, NETWORK 10K
RB405	1-233-803-91	RES, NETWORK 1.5K
RB406	1-233-792-91	RES, NETWORK 100K
RB408	1-233-415-21	RES, CHIP NETWORK 10K
RB409	1-233-415-21	RES, CHIP NETWORK 10K
RB410	1-233-415-21	RES, CHIP NETWORK 10K
RB511	1-233-423-21	RES, CHIP NETWORK 47
RB517	1-233-575-21	RES, CHIP NETWORK 22
RB518	1-233-575-21	RES, CHIP NETWORK 22
RB519	1-233-575-21	RES, CHIP NETWORK 22
RB520	1-233-575-21	RES, CHIP NETWORK 22
RB521	1-233-575-21	RES, CHIP NETWORK 22
RB522	1-233-575-21	RES, CHIP NETWORK 22
RB523	1-233-575-21	RES, CHIP NETWORK 22
RB524	1-233-575-21	RES, CHIP NETWORK 22
RB525	1-233-575-21	RES, CHIP NETWORK 22
RB526	1-233-575-21	RES, CHIP NETWORK 22
RB527	1-233-575-21	RES, CHIP NETWORK 22
RB528	1-233-575-21	RES, CHIP NETWORK 22
RB529	1-233-575-21	RES, CHIP NETWORK 22
RB530	1-233-575-21	RES, CHIP NETWORK 22
RB531	1-233-575-21	RES, CHIP NETWORK 22
RB532	1-233-575-21	RES, CHIP NETWORK 22
RB602	1-233-415-21	RES, CHIP NETWORK 10K

Ref.	Part No.	Description
RB603	1-233-415-21	RES, CHIP NETWORK 10K
RB606	1-233-412-21	RES, CHIP NETWORK 1.0K
RB607	1-233-415-21	RES, CHIP NETWORK 10K
RB609	1-233-423-21	RES, CHIP NETWORK 47
RB611	1-233-415-21	RES, CHIP NETWORK 10K
RB803	1-233-415-21	RES, CHIP NETWORK 10K
<THERMISTOR>		
△ TH001	1-804-479-21	THERMISTOR, POSITIVE
△ TH002	1-804-478-21	THERMISTOR, POSITIVE
<CRYSTAL>		
X101	1-781-640-21	VIBRATOR, CRYSTAL
X201	1-781-640-21	VIBRATOR, CRYSTAL
X202	1-781-857-21	OSCILLATOR, CRYSTAL
X301	1-781-856-21	VIBRATOR, CRYSTAL
X302	1-781-768-21	VIBRATOR, CRYSTAL
X401	1-760-496-22	VIBRATOR, LITHIUM NIOBATE
X402	1-767-300-21	VIBRATOR, CRYSTAL

A-6712-984-A MOUNTED CIRCUIT BOARD, GB-004		

PLACE CODE #25B6		
<BATTERY>		
BT101	1-756-076-21	HOLDER, LITHIUM BATTERY
<CONNECTOR>		
CN101	1-815-648-21	PIN, CONNECTOR (PC BOARD) 2P

A-6712-983-A MOUNTED CIRCUIT BOARD, SW-363		

PLACE CODE #25SW		
<CONNECTOR>		
CN751	1-785-470-21	CONNECTOR, FPC(LIF(NON-ZIF)7P
<DIODE>		
D751	8-719-078-90	DIODE CL-165HR/G1-D-T
D752	8-719-080-04	DIODE CL-190UB-X-T
<TRANSISTOR>		
Q751	8-729-013-97	TRANSISTOR RN1304-TE85L
Q751	8-729-029-14	TRANSISTOR DTC144EUA-T106
<RESISTOR>		
R751	1-216-833-71	RES, CHIP 10K
R751	1-216-833-81	RES, CHIP 10K
R751	1-216-833-91	RES, CHIP 10K
R751	1-220-740-51	RES, METAL FILM 10K
R752	1-216-835-91	RES, CHIP 15K
R753	1-216-993-91	RES, CHIP 2.4K
<SWITCH>		
S751	1-771-917-21	SWITCH, TACTILE
S752	1-771-917-21	SWITCH, TACTILE

Ref.	Part No.	Description	
SUPPLIED ACCESSORIES			PLACE CODE #23

△ AC	1-751-115-21	CORD, POWER	SCPH-30003D'
MC	3-066-441-11	MASTER CARTON, 3 SETS	SCPH-30003D'
△ AC	1-575-131-82	CORD, POWER	SCPH-30004D'
MC	3-066-441-01	MASTER CARTON, 3 SETS	SCPH-30004D'
CONV	1-573-291-12	CONNECTOR, CONVERSION	
AV	1-792-028-11	CORD, CONNECTION	
CONT	1-792-238-72	CORD, CONNECTION	
SH	3-060-494-01	SHEET, PROTECTION	
CU	3-064-714-01	CUSHION	
PA	3-065-172-01	PAD, TOGETHER PACKING	
CA	3-066-440-12	INDIVIDUAL CARTON	
MANUAL BLOCK ASSY			PLACE CODE #23

RE	3-066-159-02	CARD (B), OWNER REGISTRATION	
			for SCPH-30003D'
DISC	3-066-725-02	DISK, DEMONSTRATION	for SCPH-30003D'
IN	3-068-129-12	INSTRUCTION	for SCPH-30003D'
IM	3-068-537-32	MANUAL, INSTRUCTION	for SCPH-30003D'
SE	3-987-375-02	SEAL, SEAL	for SCPH-30003D'
RE	3-066-160-03	CARD (C), OWNER REGISTRATION	
			for SCPH-30004D'
IN	3-068-130-13	INSTRUCTION	for SCPH-30004D'
IM	3-068-537-42	MANUAL, INSTRUCTION	for SCPH-30004D'
IM	3-068-537-52	MANUAL, INSTRUCTION	for SCPH-30004D'

Ref. Part No. Description

Ref. Part No. Description

Ref. Part No. Description



SCPH-30001D
SCPH-30002D
SPCH-30003D
SPCH-30004D

SCPH30000 series SERVICE MANUAL

3rd edition
for D type MD and CONSOLE structure only

PlayStation®2



Sony Computer Entertainment Inc.
Customer Service Department
Published in Japan c2.2001 9-927-086-03

NOTICE

This service manual published ©2.2001 by Sony Computer Entertainment Inc.. All right received. Reproduction and distribution without the permission of Sony Computer Entertainment Inc. is strictly prohibited. Commercial use or Rental prohibited. This service manual is the proprietary property of Sony Computer Entertainment Inc.. It's use is authorized person who work for PlayStation®2 only.

REVISIONS

Design and Specification are subject to change without notice.

CAUTION

This use of optical instruments with this product will increase eye Hazard. As the laser beam used in this PlayStation®2 is harmful to eyes do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25 CM FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

CAUTION for electric shock

When power is ON, Don't touch to Power block, AC-inlet, Power switch and so on, not to get an electric shock at repair.

CAUTION for burning

When current is supplied, Some of part surface temperature like EE, GS, Regulator-IC, Power supply, Optical device and so on. These part surface is become high temperature condition. When it repair, Don't touch them at a time during it surface is high temperature condition to take prevent against burning. Do repair after it is cooled down enough.

NOTIFICATION for environmental assessment

This model is CR2032 lithium battery on board inside on the GB003 as timer back-up power. CR2032 life may be about 5-8 years so you have very few need for changing to new one. But if you have necessary to new one or disassemble for scrapping, you have to keep your to country low, regulation, standard, etc. of environmentl assess-ment and safety.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instruction.

ADVARSEL!

Lithiumbatteri-Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. lever det brugte batteri tilbage til leverandøren.

ADVARSEL

Eksplosjonsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

VARNING

Explosionsfara vid felaktigt batteribyte. använt samme batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan valmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

Table of contents

• CONSOLE	3
• MD BLOCK	23


CAUTION for static electricity


For disassemble and assemble the console, Don' t charge static electricity on your body and around equipment. Get rid static electricity by grounding your body and around equipment.

Static electricity will be destroyed key devives like ICs, OPT and etc.

71 LABEL, MODEL
NUMBER


112 TAPE, VOID





CAUTION

When tighten the BV316 and M354 screws,
Tighten them in order to the steps shown figure.



75 COVER, SCREW


76 CAP

BV316 SCREW (2 LOCK),
+BV TAPPING

M354 SCREW (M3 X 54),
HEAD TAPPING


Never scratch for CAPs and SCREW COVERS
when removing them.

TOOLS : SCREW DRIVER (+ #3)




92 SWITCH BLOCK ASSY

94 UPPER COVER ASSY




- 50 BUTTON, SWITCH
- 51 BRACKET, SWITCH
- 52 TPG +P 2 X 8,
TYPE 2, NON-SLIT
- 53 SW-358 MOUNT
SW-363 MOUNT



TOOLS : SCREW DRIVER (+ #0)

62 TERMINAL BOARD
(FRONT)

BV312 SCREW,
TAPPING +BV 3 x 12




TOOLS : SCREW DRIVER (+ #3)

CAUTION

For exchanging the LOWER COVER ASSY. to new one,
Check the carved seal on surface of LOWER COVER ASSY.

93 COVER ASSY,LOWER




CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

 (60) POWER BLOCK


(P360) SCREW +P 3 X 6



CAUTION

The components identified by mark  or dotted line with mark.
 are critical for safety. Replace only with part number specified.

TOOLS : SCREW DRIVER (+ #3)



CAUTION


Never lose the fitting of INSULATING SHEET put on the SHIELD(B) when assemble the console.

CAUTION

Never lose the fitting of LABELs put on the SHIELD(B) when assemble the console.

⚠ (157) SHEET, INSULATING


⚠ (160) LABEL, CUTION,
BARRIER
for SCPH-30001



CAUTION

The components identified by mark ⚠ or dotted line with mark.
⚠ are critical for safety. Replace only with part number specified.


⚠ 64 SWITCH, POWER
(WITH AC INLET)



CAUTION

The components identified by mark ⚠ or dotted line with mark.

⚠ are critical for safety. Replace only with part number specified.




63 DC. FAN


159 PANEL, REAR

BV312 SCREW, TAPPING
+BV 3 X 12

TOOLS : SCREW DRIVER (+ #3)



TOOLS : SCREW DRIVER (+ #0)





Never lose the fitting of SHEET(DRIVER),
ELECTRIC HEAT put on the IC802 and IC803
when assemble the console.


151 CABLE, FLAT
(FFC-011)

152 CABLE, FLAT
(FFC-012)

153 HARNESS (HS-059)








Never lose the fitting SHEET(A) ELECTRIC HEAT
put on SHIELD(A) ASSY. when assemble the console.

CAUTION

Don't touch the OPTICAL DEVICE not to broken it.

97. SHIELD (A) ASSY




CAUTION

For dumping the consumed CR2032 Lithium battery,
Obey your country law Standard procedures.

⚠ 61 BATTERY, LITHIUM
(CR2032 TYPE)

GB003 GB-003/-004 MOUNT



CAUTION

The components identified by mark ⚠ or
dotted line with mark.
⚠ are critical for safety. Replace only with
part number specified.

BACK


CAUTION

PULLEY BRACKET change to new one by repaier
LABEL has to put on new PULLEY BRACKET due
to in your country law and standart procedure for safty.

91 MD BLOCK ASSY


! 103 LABEL, CAUTION

! 104 LABEL, LASER
CAUTION



CAUTION


Don't touch the place surrounded square shown figure when tighten screws.



17 TAPPING (B2 X 6.5)

27 PULLEY,
BRACKET ASSY

TOOLS : SCREW DRIVER (+ #0)




17 TAPPING (B2 X 6.5)

28 TRAY ASSY

95 PLATE ASSY,
ORNAMENTAL


TOOLS : SCREW DRIVER (+ #0)

- 5 SCREW (B2 X 6.5),
SHAFT RETAINER




TOOLS : SCREW DRIVER (+ #0)

TOP SIDE VIEW



BOTTOM SIDE VIEW



4 PWB, FLEXIBLE

13 SHAFT, MAIN

14 RACK

16 SCREW, SKEW


22 0 PLATE 3 MAIN
M2 X 3.2

⚠ 23 DEVICE, OPTICAL
KHS-400B

TOOLS : SCREW DRIVER (+ #0)
HEXAGRAM SCREW DRIVER (T5)

32 SCREW,
CAM RETAINER


33 CAM, TILT



TOOLS : SCREW DRIVER (+ #0)

3 MOTOR, DC

17 TAPPING (B2 X 6.5)




TOOLS : SCREW DRIVER (+ #0)

22 0 PLATE 3 MAIN
M2 X 3.2


35 GUIDE (L)

36 GUIDE (R)

37 SCREW, SKEW




TOOLS : SCREW DRIVER (+ #0)



2 SPINDLE
MOTOR, DC


22 0 PLATE 3 MAIN
M2 X 3.2



TOOLS : SCREW DRIVER (+ #0)

22 0 PLATE 3 MAIN
M2 X 3.2


34 SPRING (TILT),
LEAF



TOOLS : SCREW DRIVER (+ #0)

9 SCREW, STEP


32 SCREW (SUB), STEP



TOOLS : SCREW DRIVER (+ #0)


8 INSULATOR

10 CHASSIS ASSY,
MAIN



7 SUB FRAME ASSY

30 MAIN FRAME ASSY




MF4 BELT, RUBBER

MF5 COVER GEAR

MF6 TAPPING (B2 X 6.5)

MF7 SWITCH LEAF





TOOLS : SCREW DRIVER (+ #0)

MF1 CAM, SLIDE

MF2 PULLEY

MF3 GEAR, DRIVING





MF6 TAPPING (B2 X 6.5)

MF8 SWITCH LEAF

MF9 LOADING MOTOR, DC

BACK

COVER PAGE

TOOLS : SCREW DRIVER (+ #0)